Haier

SERVICE MANUAL

Order No.AC1101S020V0

Wall mounted Type

DC Inverter EA-Series

Model No. HSU09VHJ(DB)

⚠WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public.
It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death

©2011(Qingdao Haier Air Conditioner General corp.,Ltd)
All right reserved .Unauthorized copying and distribution is a violation of law

Haier Group

Table of Contents

1. Introduction 1
2. List of Functions 6
3. Specifications 7
4. Printed Circuit Board Connector Wiring Diagram 9
5. Functions and Control 14
5.1 Main functions and control specifications of indoor unit 14
5.2 Main functions and control specifications of outdoor unit 20
5.3 Function of main thermistor 25
5.4 Value of thermistor 26
6. System Configuration 41
6.1 System Configuration 41
6.2 Instruction 41
7. Service Diagnosis 49
7.1 Caution for diagnosis 49
7.2 Problem Symptoms and Measures 49
7.3 Error codes and description indoor display 50
8. Installations 66
9. Removal Procedure 70
9.1 For indoor unit 70
9.2 For outdoor unit 82
10. Wiring Diagrams 91
10.1 Indoor Unit 91
10.2 Outdoor Unit 92
11. Circuit Diagrams 93
12. Description of Coding rules of Unit Model 97

1. Introduction

1.1 Safety Cautions

Be sure to read the following safety cautions before conducting repair work.

The caution items are classified into “Warning” and “Caution”. The “Warning” items are especially important since they can lead to death or serious injury if they are not followed closely. The “Caution” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.

About the pictograms

△ This symbol indicates an item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.

○ This symbol indicates a prohibited action.
The prohibited item or action is shown inside or near the symbol.

● This symbol indicates an action that must be taken, or an instruction.
The instruction is shown inside or near the symbol.

After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.

1.1.1 Caution in Repair

Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for a repair. Working on the equipment that is connected to a power supply can cause an electrical shook. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas.The refrigerant gas can cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work.A charged capacitor can cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or fire.	

Warning	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands can cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor.	
Be sure to check that the refrigerating cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the refrigerating cycle section is hot can cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.	

1.1.2 Cautions Regarding Products after Repair

Warning	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can cause an electrical shock, excessive heat generation or fire.	
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment can fall and cause injury.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting in injury.	For integral units only
Be sure to install the product securely in the installation frame mounted on a window frame. If the unit is not securely mounted, it can fall and cause injury.	For integral units only

Warning	
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	
Do not mix air or gas other than the specified refrigerant (R-410A / R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

Caution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If a combustible gas leaks and remains around the unit, it can cause a fire.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.	For integral units only

1.1.3 Inspection after Repair

Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way. If the plug has dust or loose connection, it can cause an electrical shock or fire.	
If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.	

Warning	
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it can cause an electrical shock, excessive heat generation or fire.	

Caution	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections can cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 M ohm or higher. Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage can cause the water to enter the room and wet the furniture and floor.	

1.1.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.1.5 Using Icons List

Icon	Type of Information	Description
Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, get an unexpected result or has to restart (part of) a procedure.
Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

2. List of Functions

Category	Functions	HSU09VHJ(DB)
Healthy negative ion	make your room full of an abundance natural negative ions.	Y
Left&right flow	With specialized motor and flaps, the airflow can be adjusted .	N
Child lock	Avoid the child's wrong operation on the remote controller	Y
3D air flow	The 3D airflow is able to deliver the airflow horizontally and vertically.	N
24Hour timer	Use the timer function to set on,or off,or from on to off,or from off to on	Y
Auto restart	automatic return to previous operation conditions after asundden power blackou	Y
Easy clean design	The panel is easy to wash and the airflow vents can be detached easily	Y
Intelligent air	With single-blade technology ,the airflow can be adjusted not to blow directly	Y
Anti-mold filter	Catches most small particles and remove unpleasant odors effectively.	Y
Sleep mode	The setting temprature and the indoor noise can be adjusted to a more comfortable level when you set the "sleep mode"during night sleep	Y
4 Fan setting	Select the fan speed LO,MED,HI,AUTO	Y
Entire auto mode	You can set a tempreture value,with which the unit can be adjusted the operation mode automatically	Y
Auto mode	adjust the last fixed operation mode automatically.	N
ESF filter	Trap harmful dust and remove unpleasant odors effectively	N
Power mode	Quick cooling or heating	Y
Soft mode	lower noise operation condition	Y
Negative ion filter	Generate negative ions by the filter.	N
Constant temperature dehumidification	Make dehumidifying in the room while keeping the constant temperature inside	N

Note: Y: Holding Functions
N : No Functions

3. Specifications

Model			HSU09VHJ(DB)	
			Cooling	Heating
Capacity Rated (Min.~Max.)		kW	3.51(1.47-4.1)	3.93(1.35-4.1)
		Btu/h	12000(5000-14000)	13400(4600-14000)
		kcal/h	3018.6(1260-3520)	3380(1160-3530)
Moisture Removal		/h	3.38	—
Running Current (Rated)		A	5.4	5.9
Power Consumption Rated (Min.~Max.)		W	1090(180-1375)	190(260-1400)
Power Factor		%	98	98
SEER/HSPF			16.8	9.5
Piping Connections	Liquid	mm	φ6.35	
	Gas	mm	φ9.52	
	Drain	mm	φ16.0	
Heat Insulation			Both Liquid and Gas Pipes	
Max. Interunit Piping Length		m	15	
Max. Interunit Height Difference		m	10	
Chargeless		m	10	
Amount of Additional Charge of Refrigerant		g/m	20	
Indoor Unit				
Front Panel Color			White	
Air Flow Rate	m³/min(cfm)	H	8	8
		M	7. 2	7. 2
		L	6. 3	6. 3
		SL	4.8	4.8
Fan	Type		Cross Flow Fan	
	Motor Output	pints W	30	
	Speed	Steps	4 Steps, Auto	
Air Direction Control			Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.15	0.15
Power Consumption (Rated)		W	33	33
Temperature Control			Microcomputer Control	
Dimensions (H×W×D)		mm	938x187x265	
Packaged Dimensions (H×W×D)		mm	998x262x316	
Weight		kg	24.03	
Gross Weight		kg	27.78	
OperationSound	H/M/L	dBA	46/ 43/39	
Sound Power	H	dBA	54	54

Outdoor Unit				
Casing Color			White	
Compressor	Type		Rotary Compressor	
	Model		DA89X1C-20FZ	
	Motor Output	W	650	
RefrigerantOil	Model		ESTER OIL VG74	
	Charge	L	0.37	
Refrigerant	Model		R410a	
	Charge	oz	35.5	
Air Flow Rate (H/L)	m³/min		31.6	31.6
	cfm		1115	1115
Fan	Type		Propeller	
	Motor Output	W	80	
Running Current (Rated)		A	3.5	3.5
Power Consumption (Rated)		W	780	780
Power Factor		%	98	98
Starting Current		A	20	
Dimensions (H×W×D)		mm	543x783x255	
Packaged Dimensions (H×W×D)		mm	599X915X325	
Weight		lb	72.75	
Gross Weight		lb	79.37	
OperationSound	H/L	dBA	53	49
Sound Power	H	dBA	63	59

Note: The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 80°FDB/67°FWB Outdoor ; 95°FDB/75°FWB	Indoor ; 70°FDB/60° FWB Outdoor;47° FDB/47°FWB	5m

Conversion Formulae
kcal/h=kW×860
Btu/h=kW×3414
cfm=m³/min×35.3

4.Printed Circuit Board Connector Wiring Diagram

4.1：Indoor unit Connectors

Connectors

PCB(1) (Control PCB)

1) CN26 Connector for fan motor
2) CN11 Connector for STEP motor
3) CN8 Connector for heat exchanger thermistor and Room temperature thermistor
4)CN27 Connector for fan feedback
5)CH1 Connector for power L wire
6)CON2 Connector for power N wire
7) CON7 Connector for communicate wire
8) CN30 Connector for transformer input
9) CN31 Connector for transformer output
10) CN32 Connector for display board

Note: Other designations

PCB(1) (INdoor Control PCB)

1) CN48 Connector for Forced operation ON / OFF switch
2) J1 Select 25 or 35
3) LED1 communicate display light
4) RV1 Varistor
5) FUSE1 Fuse 3.15A/250VAC

PCB(1)


CN26
CON12
CN27
CN32
CN1
CN11
CON2
CH1
CN30
CON8
CN31
ROOM/PIPE
STEP MOTOR
CN48
SWITCH
SW1
SW1'
CN27
PG_BACK
CN32'
CN32
C7
L1
C18
R51
IC7
J3
J4
J5
J6
J7
J8
J9
J10
J11
J12
J13
J14
J15
J16
J17
J18
E1
E3
E4
BUZZ1
CON12
(L_OUT)
BLACK
JP1
(S_TIM)
CON2
N
WHITE
C15
RV1
T3.15A/250VAC
FUSE1
(L)
CH1
K1
CX1
CX2
IC4
J19
J20
J21
J22
J23
J24
E2
IC3
XT1
J31
J25
(RX)
J26
(TX)
E6
CN30
TASNS-I
HS1
IC6
J32
K2
R8
CON8
FLZ
WHITE
RED
FLZ
CON6
CON7
S
RED
CON9
HXF
BLUE
D5
D8 D9 D7 D6
E5
IC2
IC1
LED1
D1
D2
TRANS-II
ON A
OFF B
J27
J28
J29
J30
J2
J1
ON 25
OFF 35
AHG0902V1.2

4.2 ：outdoor unit

Connectors

PCB(1) (Control PCB)

1) CN1,CN2 Connector for power N and L
2) CN3 Connector for ground
3) CN22 Connector for DC POWER 15Vand 5V to the module board
4) CN16 Connector for electric expansion valves
5) CN21 Connector for DC fan motor
6) CN10 Connector for four way valve coil
7) CN17,CN18,CN19,CN20 Connector for thermistors
(CN20: outdoor air,CN19: heat exchanger, CN18 :SUCK thermistors ,CN17 :discharge pipe)
8) CN23 Connector for communicate between the control board and the module board
9) CN25 ,CN8 Connector for the L,N to the module board
10) CN4 Connector for communicate between the indoor board and the outdoor board
11) CN26 Connector for capacitance anode
12) CN24 Connector for capacitance cathode

PCB(2) (module PCB)

CN10 Connector for the DC power 5V and 15V form the control PCB
CN11 Connector for communicate between the control board and the module board
P(CN1), N(CN5) Connector for capacitance board
LI (CN7),LO(CN6) Connector for reactor
CN2，CN3，CN4 Connector for the U, V, W wire of the compressor

Note: Other Designations
PCB(1) (Control PCB)
1) FUSE 1, (25A,250VAC) FUSE 2(1A,250VAC)
2)LED 1 keep light representative normal ,if keep flash interval representative trouble Alarm
3)RV1,RV2,RV3 Varistor

PCB(1)


CN26
CN24
CN23
CN22
CN21
CN17
CN18
CN19
CN20
CN16
CN4
CN3
CN1
CN10
CN25
CN8
CN2

PCB(2)


CN6
CN7
CN11
CN10
CN5
CN4
CN3
CN2
CN1
LO
LI
AC—L
AC—N
N
W
V
U
P
2005006V10

5.Funcitions and Control

5.1 Main functions and control specification of indoor unit

This specification use for HSU18VHJ（DB）frequency conversion air condition are manufactured by Haier air condition parent company. "Setting value" (express in parameter) in this specification means is a parameter that is stored in EEPROM. Refer to [EEPROM parameter table].

5.1.1 Temperature Adjusting function

5.1.1.1 Temperature adjusting of different levels.

(DASH operation conditions under different modes)



5.1.1.2 Select the wind volume when it is set automatic

When the wind volume is automatic, it can be switched between strong, medium and weak according to the temperature adjusting levels.

Wind volume under the automatic wind volume mode

	Temperature adjusting levels								
	A	B	C	D	E	F	G	H	I
Heating	Strong	Strong	Strong	Strong	Strong	Medium	Weak	Weak	SLO
cooling		Strong	Strong	Strong	Medium	Medium	Weak	Weak	Weak
Moisture removing		Strong	Medium	Medium	Medium	Weak	Weak	SLO	SLO

5.1.1.3 Wind volume limit

When the compressor is working and the max setting for indoor fan motor is medium or weak, the upper limit of indicated frequency is as follows:

Frequency control form for wind volume

	Limited frequency variables	Limited frequency
Medium wind volume	FQLIMMD	70Hz
Weak wind volume	FQLIMLO	58Hz
Limited frequency for up/down health wind	FUPHEAL	48Hz

5.1.2 Main functions

5.1.2.1 Warm boot

When the heat running starts or the frost removing ends and the compressor starts again, in order to avoid cold wind, warm boot wind volume control should be done.



To control the indoor fan motor as shown in the table above according to the heat exchange temperature

The fan motor stops when the heat exchange temperature is below 25℃

The fan motor is working slightly weak when the heat exchange temperature is above25 ℃ and below 35℃

The fan motor is working weak when the heat exchange temperature is above35 ℃ and below 37℃

The fan motor works as set if the he heat exchange temperature remains above 38℃

5.1.2.2 When the compressor stops and remains idle for 3 minutes

20 seconds after the compressor stops, the up wind volume is weak (switching to SSLO in silent running mode) and then slightly weak. While the down wind volume is stoped

If the compressor stops when the heat running starts, the wind volume is weak

5.1.2.3 Dehumidification running

Under the dehumidification mode the fan motor stops as the compressor stops

The operation is weak after 3 minutes' idle mode

After stand by for 3 minutes, the compressor is on.

The compressor operates as the set wind volume when the wind volume is set to be strong, medium or weak

The wind volume is decided according to the temperature adjusting when the wind volume is set to be automatic.



5.1.2.4 Automatic running

When the running mode is turned to automation after starting the system, the system will first determine the running mode according to the current room temperature and then will run according to the determined mode. Tr in the following selection conditions means room temperature, Ts means setting temperature, Tp means temperature of indoor coil pipe

Tr≥23℃ Choose Cooling Mode

Tr＜23℃ Choose Heating Mode

After turning to the automation mode, the running mode can be switched between cooling mode, fan mode and heating mode according to the change of the indoor ambient temperature. But the automatic conversion between cooling mode and heating mode must be conducted after 15 minutes.

5.1.3 Special functions

5.1.3.1 Powerful running

Powerful running for 15 minutes

The running stops or ends the powerful running after 15 minutes

The mode switch ends the powerful running

Enter into the silent mode, normal running mode or timed switching on mode to end the powerful running

When in automatic mode, there are powerful and silent functions for your choice. When the main unit is in cooling mode, it operates with powerful cooling or silent cooling. When the main unit is in heating mode, it operates with powerful heating or silent heating. When the main unit is in wind-sending mode, there are no powerful or silent modes.

There is no powerful mode for wind-sending and moisture removing

Powerful heating：

Change the set temperature. With temperature adjusting function

The wind volume is the automatic medium

When in frost removing mode, the outdoor unit does not accept the communication signal for powerful running

After 15 minutes of powerful running, the compressor can not be off within 10 minutes

Powerful cooling：

Change the set temperature. With temperature adjusting function

The wind volume is the automatic strong

After the compressor starts, there will be no low-intense running protection within 3 minutes

5.1.3.2 Silent running

Send the silent running signal to the outdoor unit

Under the Silent hearing mode,The wind volume is SSLO after the compressor is on,The wind volume will be kept SSLO within 20 seconds after the compressor stops and then changes to weak

Under the Silent cooling mode the wind volume is SSLO

There is no silent mode for moisture removing and wind-sending.

5.1.3.3 Air cleaning

If the fan motor starts working after receiving the remote-control order, the aion generator starts working and sends out ions.

The ion generator stops as the fan motor stops.

When the ion generator is OFF and the air cleaning function is on, the fan motor starts running and the ion generator starts working again.

5.1.3.4 Timed running

Set the time duration according to the time difference between the clock for timing and the current clock

In timing mode, the display panel will flash the light at fixed times

Timed OFF	When this function is set, operation modes on the panel display will not change. The timing icon will show and the operation stops when the set time comes.
Timed ON	When this function is on, the panel display will only display a question mark. The unit will operate as the set mode when the time comes.
Timed ON/OFF	The unit will start operating or stop according to the order of your setting.

5.1.3.5 Sleeping function

a.After setting the sleeping function, the refrigerating mode and dehumidification mode will run as per the following rules:



b.After setting the sleeping function, the heating mode will run as per the following rules:



As shown in the above diagram, after running for 1 hour under refrigerating mode and dehumidification mode, the setting temperature will increase about2℉; after another 1 hour, it will increase about2℉ again, and after 6 hours, it will cease; after running for 1 hour under heating mode, the setting temperature will decrease about4℉, after another 1 hour, it will decrease the about 4℉ again, and after 3 hours, it will increase about 2℃, and after other 3 hours, it will cease.

5.1.3.6 Trial running

The indicated frequency for trial running is 58Hz, wind volume is strong.

The trial running will last for 30 minutes and then the unit will be powered off. The unit will exit the trial running if it receives any remote-control signal during the trial running period.

There is no low-intense running protection.

5.1.3.7 Power failure compensation

To enter into the function please press the sleep key 10 times with 4 beeps in 7 seconds

Under the power failure compensation mode, unplug and plug again ,the indoor unit will resume original operation

Under the power failure compensation mode, unplug and plug again, the unit will be on OFF state.

Mode, Fan speed, Healthy, Set temperature can be memoried. Swing, Timer, Sleep cannot be

memoried

Press the sleep key for 10 times with 2 beeps in 7 seconds to exit.

5.1.3.8 Rated Operation

Rated Cooling:

When receiving the instruction of indoor unit rated operation, the unit will start rated cooling operation.

Rated Heating:

When receiving the instruction of indoor unit rated operation, the unit will start rated heating operation.

5.2 Main functions and control specification of outdoor unit

Sensor Code Definition: Tai= Indoor Ambient Temperature, Tao=Outdoor Ambient Temperature, Tc1=Indoor Coil, Td= Air Discharge, Te= Outdoor Coil, Ts=Air Intake

5.2.1 Outdoor Unit Operation Frequency and Control

Compressor Operation Frequency Range

Compressor Operation Frequency Range:

Outdoor Temperature	≤4	4∽18	≥18
Heating（Hz）	20∽110	20∽90	20∽53
Defrosting（Hz）	80		
Outdoor Temperature	≤23	23∽32	≥32
Cooling（Hz）	20∽50	20∽70	20∽95

Compressor Startup

Regardless of target frequency of indoor unit, each time when compressor is from off to on, it must maintain 60Hz,90Hz for one minute (Frequency will be immediately decreased under the condition that outdoor unit air discharge temperature overheating protection is activated or over current of compressor) then the compressor will operate towards target frequency. This process does not exist in normal operation of unit.

Heating

When completing compressor startup operation, it will operate as per frequency of indoor unit.

After 2 minutes, compressor operation frequency will be compensated as per relevant conditions.

Cooling & Dehumidification:

When completing compressor startup operation, it will operate as per frequency of indoor unit.

After 2 minutes, compressor operation frequency will be compensated as per relevant conditions.

Compressor Frequency Increase/Decrease Speed

Rapid Frequency Increase/Decrease Speed 1 ----------1Hz/s

Slow Frequency Increase/Decrease Speed 2 ----------1Hz/10s

5.2.2 Outdoor fan control

Compressor startup within 3min ,outdoor fan speed control as follows:

Outdoor Temperature	＜10	10∽25	≥25
Cooling/ Dehumidification	1	3	7
Heating	5	3	2

fter compressor runs 3min ,outdoor fan speed control as follows:

Cooling/ Dehumidification:

Compressor Operation Frequency（Hz）		＜25	25∽45	≥45
Tao（℃）	32 ∽38	3	4	7
	23∽32	1	2	5
	＜23			
	≥38	7		

Heating:

Compressor Operation Frequency（Hz）		＜25	25∽45	≥45
Tao（℃）	≤4	3	4	7
	4∽18	2	4	7
	≥18	1		

Compressor shutdown and outdoor fan residual heat blow process

When compressor shuts down in cooling mode, outdoor fan automatically jumps to low speed and blows residual heat for 30s and stop.

5.2.3 Four-way Valve Control

Defrosting Four-way Valve Control，(please see defrosting process for details)

Time sequence of the defrosting operation is as follows:

Four-way Valve Work Status in Other Modes:

In heating mode, four-way valve is on. If compressor is off or is switched to non-heating mode, four-way valve ensures that it is off at least 2 minutes after compressor shuts down.

5.2.4 Outdoor Defrosting Control

Defrosting Mode Entry Conditions

The unit will enter defrosting mode when compressor starts up and operates for 10 minutes continuously in heating mode or after compressor runs for an accumulated time of 45 minutes (Upon completion of defrosting or when switched to cooling mode, compressor accumulated operation time will be cleared) and when 2 minutes' continuous checking by defrosting sensor TE (check frosting condition of outdoor unit heat exchanger) and outdoor ambient temperature sensor TA meets the following conditions:

TE≤C×TA－α

Among which: C:TA＜0℃，C=0.8

TA≥0℃，C=0.6

For area prone to frost, the value is set at 6 when unit leaves the factory.

Defrosting entry temperature control -15℃≤C×TA－α≤-5℃

Defrosting Time Interval

time interval between two defrosting cycles is 45 minutes.

Defrosting Operation

When defrosting begins, compressor will stop for one minute, external fan is running and 50s later, four-way valve will be off.

When compressor starts, external fan will be off, compressor will run at 58Hz for 60s then move on to target frequency of 88Hz.

During defrosting, compressor current and air discharge overheat protection features are effective. During defrosting, if compressor shuts down due to activation of protection feature or due to malfunction, it will resume after 3 minutes. In the unit is still within defrosting cycle, it will resume defrosting and startup of compressor will be based on the rule for defrosting startup. (The unit will exit defrosting mode and handle fault in the event of 3 consecutive restart failures.)

On entering defrosting, it must guarantee that compressor will operate for a minimum of 2 minutes in defrosting mode before exit.

Defrosting Exit Condition

When one of the following conditions is met, defrosting operation will be switched to heating operation.

（1）:Temperature of outdoor heat exchanger exceeds 7℃ for 80s continuously

（2）: Temperature of outdoor heat exchanger exceeds 12℃ for 5s continuously

（3）:Defrosting operation continues for 11 minutes.

When defrosting exit conditions are met, the unit will operate as follows

Compressor stops and external fan starts, 50s later, four-way valve will be on, 60s later, compressor will operate as per startup process.

5.2.5 PTC Output Control

When outdoor unit is energized, PTC output value is 0, 10s later, output value is 1.

When compressor stops for 10 minutes continuously, PTC output value is 0.

On receiving compressor startup instruction, initial PTC output is 1, and compressor startup will be performed 5s later.

5.2.6 System Protection Function

5.2.6.1 3 minutes stand-by time

Time interval between compressor shutdown and restart is set at 3 minutes to ensure that compressor will only restart after 3-minute shutdown and initial energization valves are turned on to adequate opening position after being fully turned off.

5.2.6.2 TD High Temperature Protections

As long as unit is on, the TD air discharge overheat protection feature will be activated, yet air discharge sensor fault must be alarmed 4 minutes after compressor starts.

TD（℃）



When TD>117℃ for 20s continuously，air discharge overheat protection will be activated and fault will be reported to indoor unit.

It will not continue in other conditions.

5.2.6.3 Indoor Heat Exchanger Anti-freeze Protection

Anti-freeze during cooling



When TC < 5℃，compressor frequency will drop at a speed of 1HZ/10s

When TC starts to rise，and 6 ≤ TC ≤ 9℃，compressor frequency will remain unchanged.

When 9 < TC < 11℃, frequency will rise nomal.

If TC ≤ 0℃，for 2 consecutive minutes, compressor will shutdown and outdoor fault lamp blinks. Fault will not be reported to indoor unit.

When compressor shuts down for more than3 minutes，and when TC>9℃，compressor will restart.

5.2.6.4 Outdoor Temperature Limit

Cooling: When outdoor temperature is lower than 23℃, cooling operation will start, compressor frequency is limited to less than 50 HZ, outdoor wind speed is forced at level 1.

Heating: When outdoor temperature is higher than 18℃, heating operation will start, compressor frequency is limited to less than 53 HZ, outdoor wind speed is forced at level 1.

5.2.6.5 Special Features

1. Forced Cooling: When receiving indoor forced cooling signal, cooling operation will start in a frequency signaled by indoor unit. Only air discharge temperature and over current protection features are effective and other protection features are invalid.

2. Rated, Middle and Minimum Capacity Operation: When receiving indoor, rated, middle and minimum capacity operation signal, outdoor unit will operate as per wind speed and frequency set by EEPROM and all the protection features are effective.

5.2.6.6 Fault Display and Treatment

In case outdoor unit faults, the alarm indicator lamp will blink and blink frequency is 1HZ，Time interval between blink cycles is 3s.

Alarm indicator lamp is off when there is no fault.

5.3 Function of Main Thermistor



Note: A:Outdoor suction temperature sensor
B: Exhaust temperature sensor
C: Indoor heat-exchange sensor

Outdoor Suction Temperature Sensor

The outdoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.

Exhaust Temperature Sensor

The discharge pipe thermistor is used for controlling temperature of the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation halts.

Indoor heat-exchange sensor

1.The indoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.

2.The indoor heat exchanger thermistor is used for preventing freezing.During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation halts.

3.The indoor heat exchanger thermistor is used for anti-icing control.During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C, it is assumed as icing.

5.4 Value of Thermistor

5.4.1 intdoor Unit

Room sensor

R25℃=23KΩ±3.5%

B25℃/50℃=4200K±3%

Temp.(℃)	Max.(KΩ)	Normal(KΩ)	Min.(KΩ)	Tolerance(℃)	
-30	568.8372	501.0746	440.8435	-1.97	1.75
-29	530.9600	468.6491	413.1441	-1.95	1.74
-28	495.8488	438.5314	387.3645	-1.93	1.72
-27	463.2850	410.5433	363.3602	-1.91	1.71
-26	433.0683	384.5212	340.9980	-1.90	1.70
-25	405.0156	360.3153	320.1558	-1.88	1.69
-24	378.9588	337.7879	300.7211	-1.86	1.67
-23	354.7440	316.8126	282.5905	-1.84	1.66
-22	332.2300	297.2732	265.6686	-1.82	1.64
-21	311.2873	279.0627	249.8676	-1.80	1.63
-20	291.7969	262.0831	235.1067	-1.78	1.62
-19	273.6494	246.2437	221.3111	-1.76	1.60
-18	256.7445	231.4612	208.4122	-1.74	1.59
-17	240.9897	217.6590	196.3462	-1.72	1.57
-16	226.3000	204.7662	185.0545	-1.70	1.56
-15	212.5973	192.7176	174.4829	-1.68	1.54
-14	199.8093	181.4531	164.5813	-1.66	1.53
-13	187.8698	170.9169	155.3033	-1.64	1.51
-12	176.7176	161.0578	146.6059	-1.62	1.49
-11	166.2961	151.8284	138.4495	-1.60	1.48
-10	156.5532	143.1847	130.7973	-1.58	1.46
-9	147.4409	135.0863	123.6153	-1.56	1.44
-8	138.9148	127.4956	116.8717	-1.53	1.43
-7	130.9337	120.3778	110.5374	-1.51	1.41
-6	123.4597	113.7009	104.5852	-1.49	1.39
-5	116.4577	107.4349	98.9897	-1.47	1.38
-4	109.8953	101.5523	93.7278	-1.45	1.36
-3	103.7422	96.0274	88.7774	-1.43	1.34
-2	97.9708	90.8365	84.1185	-1.40	1.32
-1	92.5551	85.9574	79.7322	-1.38	1.30
0	87.4712	81.3697	75.6011	-1.36	1.29
1	82.6970	77.0544	71.7088	-1.34	1.27
2	78.2118	72.9937	68.0402	-1.31	1.25
3	73.9966	69.1712	64.5813	-1.29	1.23
4	70.0335	65.5716	61.3188	-1.27	1.21
5	66.3062	62.1807	58.2405	-1.24	1.19

6	62.7992	58.9853	55.3351	-1.22	1.17
7	59.4984	55.9729	52.5917	-1.20	1.15
8	56.3905	53.1320	50.0006	-1.17	1.13
9	53.4631	50.4521	47.5523	-1.15	1.11
10	50.7048	47.9230	45.2384	-1.13	1.09
11	48.1049	45.5355	43.0505	-1.10	1.07
12	45.6534	43.2808	40.9813	-1.08	1.04
13	43.3410	41.1509	39.0236	-1.05	1.02
14	41.1592	39.1381	37.1708	-1.03	1.00
15	39.0998	37.2355	35.4167	-1.00	0.98
16	37.1553	35.4363	33.7555	-0.98	0.96
17	35.3186	33.7344	32.1818	-0.95	0.94
18	33.5833	32.1240	30.6905	-0.93	0.91
19	31.9432	30.5997	29.2769	-0.90	0.89
20	30.3925	29.1565	27.9365	-0.88	0.87
21	28.9259	27.7895	26.6651	-0.85	0.84
22	27.5383	26.4944	25.4589	-0.83	0.82
23	26.2252	25.2670	24.3140	-0.80	0.80
24	24.9822	24.1034	23.2271	-0.78	0.77
25	23.8050	23.0000	22.1950	-0.78	0.77
26	22.7500	21.9499	21.1520	-0.78	0.78
27	21.7477	20.9536	20.1638	-0.82	0.81
28	20.7951	20.0081	19.2272	-0.86	0.85
29	19.8895	19.1104	18.3394	-0.89	0.88
30	19.0285	18.2581	17.4974	-0.93	0.92
31	18.2094	17.4484	16.6988	-0.97	0.95
32	17.4302	16.6792	15.9410	-1.00	0.99
33	16.6885	15.9480	15.2217	-1.04	1.02
34	15.9825	15.2530	14.5389	-1.08	1.06
35	15.3103	14.5920	13.8903	-1.12	1.09
36	14.6700	13.9632	13.2743	-1.16	1.13
37	14.0599	13.3650	12.6889	-1.20	1.16
38	13.4786	12.7957	12.1325	-1.23	1.20
39	12.9244	12.2537	11.6035	-1.27	1.24
40	12.3960	11.7375	11.1004	-1.31	1.27
41	11.8921	11.2459	10.6218	-1.35	1.31
42	11.4113	10.7775	10.1665	-1.39	1.34
43	10.9526	10.3311	9.7330	-1.43	1.38
44	10.5147	9.9056	9.3204	-1.48	1.42
45	10.0967	9.4999	8.9275	-1.52	1.45
46	9.6976	9.1130	8.5532	-1.56	1.49
47	9.3163	8.7439	8.1965	-1.60	1.53
48	8.9521	8.3916	7.8566	-1.64	1.57
49	8.6040	8.0554	7.5327	-1.68	1.60

50	8.2713	7.7345	7.2237	-1.73	1.64
51	7.9531	7.4280	6.9291	-1.77	1.68
52	7.6489	7.1353	6.6480	-1.81	1.72
53	7.3580	6.8556	6.3797	-1.85	1.76
54	7.0796	6.5884	6.1237	-1.90	1.79
55	6.8131	6.3329	5.8793	-1.94	1.83
56	6.5581	6.0887	5.6459	-1.99	1.87
57	6.3140	5.8552	5.4230	-2.03	1.91
58	6.0802	5.6318	5.2100	-2.07	1.95
59	5.8563	5.4181	5.0065	-2.12	1.99
60	5.6417	5.2136	4.8120	-2.16	2.03
61	5.4361	5.0178	4.6260	-2.21	2.07
62	5.2391	4.8304	4.4481	-2.25	2.11
63	5.0502	4.6510	4.2780	-2.30	2.15
64	4.8691	4.4791	4.1153	-2.35	2.19
65	4.6954	4.3145	3.9596	-2.39	2.23
66	4.5287	4.1567	3.8105	-2.44	2.27
67	4.3689	4.0055	3.6678	-2.49	2.31
68	4.2154	3.8605	3.5312	-2.53	2.35
69	4.0682	3.7216	3.4004	-2.58	2.39
70	3.9268	3.5883	3.2750	-2.63	2.43
71	3.7910	3.4605	3.1549	-2.68	2.48
72	3.6606	3.3378	3.0398	-2.73	2.52
73	3.5353	3.2201	2.9294	-2.77	2.56
74	3.4150	3.1072	2.8237	-2.82	2.60
75	3.2993	2.9987	2.7222	-2.87	2.64
76	3.1881	2.8946	2.6249	-2.92	2.68
77	3.0812	2.7946	2.5316	-2.97	2.73
78	2.9785	2.6986	2.4420	-3.02	2.77
79	2.8796	2.6063	2.3560	-3.07	2.81
80	2.7845	2.5176	2.2735	-3.12	2.86
81	2.6931	2.4324	2.1943	-3.17	2.90
82	2.6050	2.3505	2.1182	-3.22	2.94
83	2.5203	2.2717	2.0451	-3.28	2.99
84	2.4388	2.1960	1.9749	-3.33	3.03
85	2.3602	2.1231	1.9075	-3.38	3.07
86	2.2846	2.0530	1.8426	-3.43	3.12
87	2.2118	1.9856	1.7803	-3.48	3.16
88	2.1416	1.9207	1.7204	-3.54	3.20
89	2.0740	1.8582	1.6628	-3.59	3.25
90	2.0089	1.7981	1.6074	-3.64	3.29
91	1.9461	1.7402	1.5541	-3.70	3.34

92	1.8856	1.6844	1.5028	-3.75	3.38
93	1.8272	1.6307	1.4535	-3.80	3.43
94	1.7709	1.5789	1.4060	-3.86	3.47
95	1.7166	1.5291	1.3603	-3.91	3.52
96	1.6643	1.4810	1.3163	-3.97	3.56
97	1.6138	1.4347	1.2739	-4.02	3.61
98	1.5650	1.3900	1.2331	-4.08	3.66
99	1.5180	1.3470	1.1937	-4.13	3.70
100	1.4726	1.3054	1.1559	-4.19	3.75
101	1.4287	1.2654	1.1194	-4.24	3.80
102	1.3864	1.2268	1.0842	-4.30	3.84
103	1.3455	1.1895	1.0503	-4.36	3.89
104	1.3060	1.1535	1.0176	-4.42	3.94
105	1.2679	1.1188	0.9860	-4.47	3.98
106	1.2310	1.0853	0.9556	-4.53	4.03
107	1.1954	1.0529	0.9263	-4.59	4.08
108	1.1610	1.0217	0.8980	-4.65	4.13
109	1.1277	0.9915	0.8707	-4.70	4.17
110	1.0955	0.9624	0.8443	-4.76	4.22
111	1.0644	0.9342	0.8189	-4.82	4.27
112	1.0344	0.9070	0.7943	-4.88	4.32
113	1.0053	0.8807	0.7706	-4.94	4.37
114	0.9771	0.8553	0.7478	-5.00	4.41
115	0.9499	0.8307	0.7256	-5.06	4.46
116	0.9235	0.8070	0.7043	-5.12	4.51
117	0.8980	0.7840	0.6837	-5.18	4.56
118	0.8734	0.7618	0.6637	-5.24	4.61
119	0.8495	0.7404	0.6445	-5.30	4.66
120	0.8263	0.7196	0.6258	-5.36	4.71

Pipe Sensor

R25℃=10KΩ ±3%

B25℃/50℃=3700K±3%

Temp.((℃))	Max.(KΩ)	Normal(KΩ)	Min.(KΩ)	Tolerance(℃)	
-30	165.2170	147.9497	132.3678	-1.94	1.75
-29	155.5754	139.5600	125.0806	-1.93	1.74
-28	146.5609	131.7022	118.2434	-1.91	1.73
-27	138.1285	124.3392	111.8256	-1.89	1.71
-26	130.2371	117.4366	105.7989	-1.87	1.70
-25	122.8484	110.9627	100.1367	-1.85	1.69
-24	115.9272	104.8882	94.8149	-1.83	1.67
-23	109.4410	99.1858	89.8106	-1.81	1.66
-22	103.3598	93.8305	85.1031	-1.80	1.64

-21	97.6556	88.7989	80.6728	-1.78	1.63
-20	92.3028	84.0695	76.5017	-1.76	1.62
-19	87.2775	79.6222	72.5729	-1.74	1.60
-18	82.5577	75.4384	68.8710	-1.72	1.59
-17	78.1230	71.5010	65.3815	-1.70	1.57
-16	73.9543	67.7939	62.0907	-1.68	1.55
-15	70.0342	64.3023	58.9863	-1.66	1.54
-14	66.3463	61.0123	56.0565	-1.64	1.52
-13	62.8755	57.9110	53.2905	-1.62	1.51
-12	59.6076	54.9866	50.6781	-1.60	1.49
-11	56.5296	52.2278	48.2099	-1.58	1.47
-10	53.6294	49.6244	45.8771	-1.56	1.46
-9	50.8956	47.1666	43.6714	-1.54	1.44
-8	48.3178	44.8454	41.5851	-1.51	1.42
-7	45.8860	42.6525	39.6112	-1.49	1.40
-6	43.5912	40.5800	37.7429	-1.47	1.39
-5	41.4249	38.6207	35.9739	-1.45	1.37
-4	39.3792	36.7676	34.2983	-1.43	1.35
-3	37.4465	35.0144	32.7108	-1.41	1.33
-2	35.6202	33.3552	31.2062	-1.38	1.31
-1	33.8936	31.7844	29.7796	-1.36	1.29
0	32.2608	30.2968	28.4267	-1.34	1.28
1	30.7162	28.8875	27.1431	-1.32	1.26
2	29.2545	27.5519	25.9250	-1.29	1.24
3	27.8708	26.2858	24.7686	-1.27	1.22
4	26.5605	25.0851	23.6704	-1.25	1.20
5	25.3193	23.9462	22.6273	-1.23	1.18
6	24.1432	22.8656	21.6361	-1.20	1.16
7	23.0284	21.8398	20.6939	-1.18	1.14
8	21.9714	20.8659	19.7982	-1.15	1.12
9	20.9688	19.9409	18.9463	-1.13	1.09
10	20.0176	19.0621	18.1358	-1.11	1.07
11	19.1149	18.2270	17.3646	-1.08	1.05
12	18.2580	17.4331	16.6305	-1.06	1.03
13	17.4442	16.6782	15.9315	-1.03	1.01
14	16.6711	15.9601	15.2657	-1.01	0.99
15	15.9366	15.2770	14.6315	-0.98	0.96
16	15.2385	14.6268	14.0271	-0.96	0.94
17	14.5748	14.0079	13.4510	-0.93	0.92
18	13.9436	13.4185	12.9017	-0.91	0.90
19	13.3431	12.8572	12.3778	-0.88	0.87
20	12.7718	12.3223	11.8780	-0.86	0.85
21	12.2280	11.8126	11.4011	-0.83	0.83
22	11.7102	11.3267	10.9459	-0.81	0.80

23	11.2172	10.8634	10.5114	-0.78	0.78
24	10.7475	10.4216	10.0964	-0.75	0.75
25	10.3000	10.0000	9.7000	-0.75	0.75
26	9.8975	9.5974	9.2980	-0.76	0.76
27	9.5129	9.2132	8.9148	-0.80	0.80
28	9.1454	8.8465	8.5496	-0.84	0.83
29	8.7942	8.4964	8.2013	-0.87	0.86
30	8.4583	8.1621	7.8691	-0.91	0.90
31	8.1371	7.8428	7.5522	-0.95	0.93
32	7.8299	7.5377	7.2498	-0.98	0.97
33	7.5359	7.2461	6.9611	-1.02	1.00
34	7.2546	6.9673	6.6854	-1.06	1.04
35	6.9852	6.7008	6.4222	-1.10	1.07
36	6.7273	6.4459	6.1707	-1.13	1.11
37	6.4803	6.2021	5.9304	-1.17	1.14
38	6.2437	5.9687	5.7007	-1.21	1.18
39	6.0170	5.7454	5.4812	-1.25	1.22
40	5.7997	5.5316	5.2712	-1.29	1.25
41	5.5914	5.3269	5.0704	-1.33	1.29
42	5.3916	5.1308	4.8783	-1.37	1.33
43	5.2001	4.9430	4.6944	-1.41	1.36
44	5.0163	4.7630	4.5185	-1.45	1.40
45	4.8400	4.5905	4.3500	-1.49	1.44
46	4.6708	4.4252	4.1887	-1.53	1.47
47	4.5083	4.2666	4.0342	-1.57	1.51
48	4.3524	4.1145	3.8862	-1.61	1.55
49	4.2026	3.9686	3.7443	-1.65	1.59
50	4.0588	3.8287	3.6084	-1.70	1.62
51	3.9206	3.6943	3.4780	-1.74	1.66
52	3.7878	3.5654	3.3531	-1.78	1.70
53	3.6601	3.4416	3.2332	-1.82	1.74
54	3.5374	3.3227	3.1183	-1.87	1.78
55	3.4195	3.2085	3.0079	-1.91	1.82
56	3.3060	3.0989	2.9021	-1.95	1.85
57	3.1969	2.9935	2.8005	-2.00	1.89
58	3.0919	2.8922	2.7029	-2.04	1.93
59	2.9909	2.7948	2.6092	-2.08	1.97
60	2.8936	2.7012	2.5193	-2.13	2.01
61	2.8000	2.6112	2.4328	-2.17	2.05
62	2.7099	2.5246	2.3498	-2.22	2.09
63	2.6232	2.4413	2.2700	-2.26	2.13
64	2.5396	2.3611	2.1932	-2.31	2.17
65	2.4591	2.2840	2.1195	-2.36	2.21
66	2.3815	2.2098	2.0486	-2.40	2.25

67	2.3068	2.1383	1.9803	-2.45	2.29
68	2.2347	2.0695	1.9147	-2.49	2.34
69	2.1652	2.0032	1.8516	-2.54	2.38
70	2.0983	1.9393	1.7908	-2.59	2.42
71	2.0337	1.8778	1.7324	-2.63	2.46
72	1.9714	1.8186	1.6761	-2.68	2.50
73	1.9113	1.7614	1.6219	-2.73	2.54
74	1.8533	1.7064	1.5697	-2.78	2.58
75	1.7974	1.6533	1.5194	-2.83	2.63
76	1.7434	1.6021	1.4710	-2.88	2.67
77	1.6913	1.5528	1.4243	-2.92	2.71
78	1.6409	1.5051	1.3794	-2.97	2.75
79	1.5923	1.4592	1.3360	-3.02	2.80
80	1.5454	1.4149	1.2942	-3.07	2.84
81	1.5000	1.3721	1.2540	-3.12	2.88
82	1.4562	1.3308	1.2151	-3.17	2.93
83	1.4139	1.2910	1.1776	-3.22	2.97
84	1.3730	1.2525	1.1415	-3.27	3.01
85	1.3335	1.2153	1.1066	-3.32	3.06
86	1.2953	1.1794	1.0730	-3.38	3.10
87	1.2583	1.1448	1.0405	-3.43	3.15
88	1.2226	1.1113	1.0092	-3.48	3.19
89	1.1880	1.0789	0.9789	-3.53	3.24
90	1.1546	1.0476	0.9497	-3.58	3.28
91	1.1223	1.0174	0.9215	-3.64	3.33
92	1.0910	0.9882	0.8942	-3.69	3.37
93	1.0607	0.9599	0.8679	-3.74	3.42
94	1.0314	0.9326	0.8424	-3.80	3.46
95	1.0030	0.9061	0.8179	-3.85	3.51
96	0.9756	0.8806	0.7941	-3.90	3.55
97	0.9490	0.8558	0.7711	-3.96	3.60
98	0.9232	0.8319	0.7489	-4.01	3.64
99	0.8983	0.8088	0.7275	-4.07	3.69
100	0.8741	0.7863	0.7067	-4.12	3.74
101	0.8507	0.7646	0.6867	-4.18	3.78
102	0.8281	0.7436	0.6672	-4.23	3.83
103	0.8061	0.7233	0.6484	-4.29	3.88
104	0.7848	0.7036	0.6303	-4.34	3.92
105	0.7641	0.6845	0.6127	-4.40	3.97
106	0.7441	0.6661	0.5957	-4.46	4.02
107	0.7247	0.6482	0.5792	-4.51	4.07
108	0.7059	0.6308	0.5632	-4.57	4.12
109	0.6877	0.6140	0.5478	-4.63	4.16
110	0.6700	0.5977	0.5328	-4.69	4.21

111	0.6528	0.5820	0.5183	-4.74	4.26
112	0.6361	0.5667	0.5043	-4.80	4.31
113	0.6200	0.5518	0.4907	-4.86	4.36
114	0.6043	0.5374	0.4775	-4.92	4.41
115	0.5891	0.5235	0.4648	-4.98	4.45
116	0.5743	0.5100	0.4524	-5.04	4.50
117	0.5600	0.4968	0.4404	-5.10	4.55
118	0.5460	0.4841	0.4288	-5.16	4.60
119	0.5325	0.4717	0.4175	-5.22	4.65
120	0.5194	0.4597	0.4066	-5.28	4.70

5.4.2 Outdoor Unit

Ambient Sensor, Suction Sensor, Defrosting Sensor

R25℃=10KΩ ±3%

B25℃/50℃=3700K±3%

Temp.(℃)	Max.(KΩ)	Normal(KΩ)	Min.(KΩ)	Tolerance(℃)	
-30	165.2170	147.9497	132.3678	-1.94	1.75
-29	155.5754	139.5600	125.0806	-1.93	1.74
-28	146.5609	131.7022	118.2434	-1.91	1.73
-27	138.1285	124.3392	111.8256	-1.89	1.71
-26	130.2371	117.4366	105.7989	-1.87	1.70
-25	122.8484	110.9627	100.1367	-1.85	1.69
-24	115.9272	104.8882	94.8149	-1.83	1.67
-23	109.4410	99.1858	89.8106	-1.81	1.66
-22	103.3598	93.8305	85.1031	-1.80	1.64
-21	97.6556	88.7989	80.6728	-1.78	1.63
-20	92.3028	84.0695	76.5017	-1.76	1.62
-19	87.2775	79.6222	72.5729	-1.74	1.60
-18	82.5577	75.4384	68.8710	-1.72	1.59
-17	78.1230	71.5010	65.3815	-1.70	1.57
-16	73.9543	67.7939	62.0907	-1.68	1.55
-15	70.0342	64.3023	58.9863	-1.66	1.54
-14	66.3463	61.0123	56.0565	-1.64	1.52
-13	62.8755	57.9110	53.2905	-1.62	1.51
-12	59.6076	54.9866	50.6781	-1.60	1.49
-11	56.5296	52.2278	48.2099	-1.58	1.47
-10	53.6294	49.6244	45.8771	-1.56	1.46
-9	50.8956	47.1666	43.6714	-1.54	1.44
-8	48.3178	44.8454	41.5851	-1.51	1.42
-7	45.8860	42.6525	39.6112	-1.49	1.40
-6	43.5912	40.5800	37.7429	-1.47	1.39
-5	41.4249	38.6207	35.9739	-1.45	1.37
-4	39.3792	36.7676	34.2983	-1.43	1.35

-3	37.4465	35.0144	32.7108	-1.41	1.33
-2	35.6202	33.3552	31.2062	-1.38	1.31
-1	33.8936	31.7844	29.7796	-1.36	1.29
0	32.2608	30.2968	28.4267	-1.34	1.28
1	30.7162	28.8875	27.1431	-1.32	1.26
2	29.2545	27.5519	25.9250	-1.29	1.24
3	27.8708	26.2858	24.7686	-1.27	1.22
4	26.5605	25.0851	23.6704	-1.25	1.20
5	25.3193	23.9462	22.6273	-1.23	1.18
6	24.1432	22.8656	21.6361	-1.20	1.16
7	23.0284	21.8398	20.6939	-1.18	1.14
8	21.9714	20.8659	19.7982	-1.15	1.12
9	20.9688	19.9409	18.9463	-1.13	1.09
10	20.0176	19.0621	18.1358	-1.11	1.07
11	19.1149	18.2270	17.3646	-1.08	1.05
12	18.2580	17.4331	16.6305	-1.06	1.03
13	17.4442	16.6782	15.9315	-1.03	1.01
14	16.6711	15.9601	15.2657	-1.01	0.99
15	15.9366	15.2770	14.6315	-0.98	0.96
16	15.2385	14.6268	14.0271	-0.96	0.94
17	14.5748	14.0079	13.4510	-0.93	0.92
18	13.9436	13.4185	12.9017	-0.91	0.90
19	13.3431	12.8572	12.3778	-0.88	0.87
20	12.7718	12.3223	11.8780	-0.86	0.85
21	12.2280	11.8126	11.4011	-0.83	0.83
22	11.7102	11.3267	10.9459	-0.81	0.80
23	11.2172	10.8634	10.5114	-0.78	0.78
24	10.7475	10.4216	10.0964	-0.75	0.75
25	10.3000	10.0000	9.7000	-0.75	0.75
26	9.8975	9.5974	9.2980	-0.76	0.76
27	9.5129	9.2132	8.9148	-0.80	0.80
28	9.1454	8.8465	8.5496	-0.84	0.83
29	8.7942	8.4964	8.2013	-0.87	0.86
30	8.4583	8.1621	7.8691	-0.91	0.90
31	8.1371	7.8428	7.5522	-0.95	0.93
32	7.8299	7.5377	7.2498	-0.98	0.97
33	7.5359	7.2461	6.9611	-1.02	1.00
34	7.2546	6.9673	6.6854	-1.06	1.04
35	6.9852	6.7008	6.4222	-1.10	1.07
36	6.7273	6.4459	6.1707	-1.13	1.11
37	6.4803	6.2021	5.9304	-1.17	1.14
38	6.2437	5.9687	5.7007	-1.21	1.18
39	6.0170	5.7454	5.4812	-1.25	1.22
40	5.7997	5.5316	5.2712	-1.29	1.25

41	5.5914	5.3269	5.0704	-1.33	1.29
42	5.3916	5.1308	4.8783	-1.37	1.33
43	5.2001	4.9430	4.6944	-1.41	1.36
44	5.0163	4.7630	4.5185	-1.45	1.40
45	4.8400	4.5905	4.3500	-1.49	1.44
46	4.6708	4.4252	4.1887	-1.53	1.47
47	4.5083	4.2666	4.0342	-1.57	1.51
48	4.3524	4.1145	3.8862	-1.61	1.55
49	4.2026	3.9686	3.7443	-1.65	1.59
50	4.0588	3.8287	3.6084	-1.70	1.62
51	3.9206	3.6943	3.4780	-1.74	1.66
52	3.7878	3.5654	3.3531	-1.78	1.70
53	3.6601	3.4416	3.2332	-1.82	1.74
54	3.5374	3.3227	3.1183	-1.87	1.78
55	3.4195	3.2085	3.0079	-1.91	1.82
56	3.3060	3.0989	2.9021	-1.95	1.85
57	3.1969	2.9935	2.8005	-2.00	1.89
58	3.0919	2.8922	2.7029	-2.04	1.93
59	2.9909	2.7948	2.6092	-2.08	1.97
60	2.8936	2.7012	2.5193	-2.13	2.01
61	2.8000	2.6112	2.4328	-2.17	2.05
62	2.7099	2.5246	2.3498	-2.22	2.09
63	2.6232	2.4413	2.2700	-2.26	2.13
64	2.5396	2.3611	2.1932	-2.31	2.17
65	2.4591	2.2840	2.1195	-2.36	2.21
66	2.3815	2.2098	2.0486	-2.40	2.25
67	2.3068	2.1383	1.9803	-2.45	2.29
68	2.2347	2.0695	1.9147	-2.49	2.34
69	2.1652	2.0032	1.8516	-2.54	2.38
70	2.0983	1.9393	1.7908	-2.59	2.42
71	2.0337	1.8778	1.7324	-2.63	2.46
72	1.9714	1.8186	1.6761	-2.68	2.50
73	1.9113	1.7614	1.6219	-2.73	2.54
74	1.8533	1.7064	1.5697	-2.78	2.58
75	1.7974	1.6533	1.5194	-2.83	2.63
76	1.7434	1.6021	1.4710	-2.88	2.67
77	1.6913	1.5528	1.4243	-2.92	2.71
78	1.6409	1.5051	1.3794	-2.97	2.75
79	1.5923	1.4592	1.3360	-3.02	2.80
80	1.5454	1.4149	1.2942	-3.07	2.84
81	1.5000	1.3721	1.2540	-3.12	2.88
82	1.4562	1.3308	1.2151	-3.17	2.93
83	1.4139	1.2910	1.1776	-3.22	2.97
84	1.3730	1.2525	1.1415	-3.27	3.01

85	1.3335	1.2153	1.1066	-3.32	3.06
86	1.2953	1.1794	1.0730	-3.38	3.10
87	1.2583	1.1448	1.0405	-3.43	3.15
88	1.2226	1.1113	1.0092	-3.48	3.19
89	1.1880	1.0789	0.9789	-3.53	3.24
90	1.1546	1.0476	0.9497	-3.58	3.28
91	1.1223	1.0174	0.9215	-3.64	3.33
92	1.0910	0.9882	0.8942	-3.69	3.37
93	1.0607	0.9599	0.8679	-3.74	3.42
94	1.0314	0.9326	0.8424	-3.80	3.46
95	1.0030	0.9061	0.8179	-3.85	3.51
96	0.9756	0.8806	0.7941	-3.90	3.55
97	0.9490	0.8558	0.7711	-3.96	3.60
98	0.9232	0.8319	0.7489	-4.01	3.64
99	0.8983	0.8088	0.7275	-4.07	3.69
100	0.8741	0.7863	0.7067	-4.12	3.74
101	0.8507	0.7646	0.6867	-4.18	3.78
102	0.8281	0.7436	0.6672	-4.23	3.83
103	0.8061	0.7233	0.6484	-4.29	3.88
104	0.7848	0.7036	0.6303	-4.34	3.92
105	0.7641	0.6845	0.6127	-4.40	3.97
106	0.7441	0.6661	0.5957	-4.46	4.02
107	0.7247	0.6482	0.5792	-4.51	4.07
108	0.7059	0.6308	0.5632	-4.57	4.12
109	0.6877	0.6140	0.5478	-4.63	4.16
110	0.6700	0.5977	0.5328	-4.69	4.21
111	0.6528	0.5820	0.5183	-4.74	4.26
112	0.6361	0.5667	0.5043	-4.80	4.31
113	0.6200	0.5518	0.4907	-4.86	4.36
114	0.6043	0.5374	0.4775	-4.92	4.41
115	0.5891	0.5235	0.4648	-4.98	4.45
116	0.5743	0.5100	0.4524	-5.04	4.50
117	0.5600	0.4968	0.4404	-5.10	4.55
118	0.5460	0.4841	0.4288	-5.16	4.60
119	0.5325	0.4717	0.4175	-5.22	4.65
120	0.5194	0.4597	0.4066	-5.28	4.70

Discharging Sensor

R80℃=50KΩ ±3%

B25/80℃=4450K±3%

Temp.((℃))	Max.(KΩ)	Normal(KΩ)	Min.(KΩ)	Tolerance(℃)	
-30	14646.0505	12061.7438	9924.4999	-2.96	2.45
-29	13654.1707	11267.8730	9290.2526	-2.95	2.44
-28	12735.8378	10531.3695	8700.6388	-2.93	2.44
-27	11885.1336	9847.7240	8152.2338	-2.92	2.43
-26	11096.6531	9212.8101	7641.8972	-2.91	2.42
-25	10365.4565	8622.8491	7166.7474	-2.90	2.42
-24	9687.0270	8074.3787	6724.1389	-2.88	2.41
-23	9057.2314	7564.2244	6311.6413	-2.87	2.41
-22	8472.2852	7089.4741	5927.0206	-2.86	2.40
-21	7928.7217	6647.4547	5568.2222	-2.84	2.39
-20	7423.3626	6235.7109	5233.3554	-2.83	2.39
-19	6953.2930	5851.9864	4920.6791	-2.82	2.38
-18	6515.8375	5494.2064	4628.5894	-2.80	2.37
-17	6108.5393	5160.4621	4355.6078	-2.79	2.37
-16	5729.1413	4848.9963	4100.3708	-2.77	2.36
-15	5375.5683	4558.1906	3861.6201	-2.76	2.35
-14	5045.9114	4286.5535	3638.1938	-2.75	2.34
-13	4738.4141	4032.7098	3429.0191	-2.73	2.34
-12	4451.4586	3795.3910	3233.1039	-2.72	2.33
-11	4183.5548	3573.4260	3049.5312	-2.70	2.32
-10	3933.3289	3365.7336	2877.4527	-2.69	2.31
-9	3699.5139	3171.3148	2716.0828	-2.67	2.30
-8	3480.9407	2989.2460	2564.6945	-2.66	2.29
-7	3276.5302	2818.6731	2422.6139	-2.64	2.28
-6	3085.2854	2658.8058	2289.2164	-2.63	2.28
-5	2906.2851	2508.9126	2163.9230	-2.61	2.27
-4	2738.6777	2368.3158	2046.1961	-2.60	2.26
-3	2581.6752	2236.3876	1935.5371	-2.58	2.25
-2	2434.5487	2112.5459	1831.4826	-2.56	2.24
-1	2296.6230	1996.2509	1733.6024	-2.55	2.23
0	2167.2730	1887.0018	1641.4966	-2.53	2.22
1	2045.9191	1784.3336	1554.7931	-2.52	2.21
2	1932.0242	1687.8144	1473.1460	-2.50	2.20
3	1825.0899	1597.0431	1396.2333	-2.48	2.19
4	1724.6540	1511.6468	1323.7551	-2.47	2.17
5	1630.2870	1431.2787	1255.4324	-2.45	2.16
6	1541.5904	1355.6163	1191.0048	-2.43	2.15
7	1458.1938	1284.3593	1130.2298	-2.41	2.14
8	1379.7528	1217.2282	1072.8813	-2.40	2.13
9	1305.9472	1153.9626	1018.7481	-2.38	2.12

10	1236.4792	1094.3200	967.6334	-2.36	2.11
11	1171.0715	1038.0743	919.3533	-2.35	2.09
12	1109.4661	985.0146	873.7359	-2.33	2.08
13	1051.4226	934.9440	830.6210	-2.31	2.07
14	996.7169	887.6792	789.8583	-2.29	2.06
15	945.1404	843.0486	751.3077	-2.27	2.04
16	896.4981	800.8922	714.8380	-2.26	2.03
17	850.6086	761.0603	680.3265	-2.24	2.02
18	807.3024	723.4134	647.6580	-2.22	2.00
19	766.4212	687.8205	616.7252	-2.20	1.99
20	727.8172	654.1596	587.4271	-2.18	1.98
21	691.3524	622.3161	559.6694	-2.16	1.96
22	656.8979	592.1831	533.3634	-2.14	1.95
23	624.3328	563.6604	508.4261	-2.12	1.93
24	593.5446	536.6540	484.7796	-2.10	1.92
25	564.4275	511.0760	462.3510	-2.09	1.90
26	536.9865	486.9352	441.1516	-2.07	1.89
27	511.0105	464.0500	421.0258	-2.05	1.87
28	486.4151	442.3499	401.9146	-2.03	1.86
29	463.1208	421.7683	383.7626	-2.01	1.84
30	441.0535	402.2430	366.5175	-1.99	1.83
31	420.1431	383.7151	350.1301	-1.97	1.81
32	400.3242	366.1295	334.5542	-1.95	1.80
33	381.5350	349.4341	319.7460	-1.93	1.78
34	363.7176	333.5801	305.6645	-1.90	1.76
35	346.8176	318.5216	292.2709	-1.88	1.75
36	330.7839	304.2151	279.5286	-1.86	1.73
37	315.5682	290.6199	267.4031	-1.84	1.71
38	301.1254	277.6976	255.8620	-1.82	1.70
39	287.4128	265.4119	244.8745	-1.80	1.68
40	274.3905	253.7288	234.4118	-1.78	1.66
41	262.0206	242.6161	224.4465	-1.76	1.64
42	250.2676	232.0436	214.9529	-1.74	1.63
43	239.0983	221.9825	205.9065	-1.71	1.61
44	228.4809	212.4060	197.2844	-1.69	1.59
45	218.3860	203.2887	189.0648	-1.67	1.57
46	208.7855	194.6066	181.2273	-1.65	1.55
47	199.6531	186.3369	173.7524	-1.63	1.54
48	190.9639	178.4584	166.6217	-1.60	1.52
49	182.6945	170.9508	159.8181	-1.58	1.50
50	174.8228	163.7951	153.3249	-1.56	1.48
51	167.3280	156.9733	147.1268	-1.53	1.46
52	160.1904	150.4683	141.2090	-1.51	1.44
53	153.3914	144.2641	135.5577	-1.49	1.42

54	146.9136	138.3454	130.1598	-1.47	1.40
55	140.7403	132.6980	125.0027	-1.44	1.38
56	134.8559	127.3081	120.0746	-1.42	1.36
57	129.2457	122.1630	115.3645	-1.40	1.34
58	123.8956	117.2504	110.8618	-1.37	1.32
59	118.7926	112.5589	106.5564	-1.35	1.30
60	113.9241	108.0776	102.4388	-1.32	1.28
61	109.2784	103.7961	98.5000	-1.30	1.26
62	104.8443	99.7046	94.7315	-1.28	1.23
63	100.6112	95.7939	91.1253	-1.25	1.21
64	96.5692	92.0553	87.6735	-1.23	1.19
65	92.7088	88.4805	84.3690	-1.20	1.17
66	89.0211	85.0614	81.2048	-1.18	1.15
67	85.4976	81.7908	78.1744	-1.15	1.12
68	82.1303	78.6615	75.2715	-1.13	1.10
69	78.9116	75.6668	72.4902	-1.10	1.08
70	75.8343	72.8004	69.8249	-1.08	1.06
71	72.8916	70.0561	67.2703	-1.05	1.03
72	70.0770	67.4283	64.8213	-1.03	1.01
73	67.3844	64.9115	62.4731	-1.00	0.99
74	64.8080	62.5006	60.2211	-0.98	0.96
75	62.3423	60.1906	58.0609	-0.95	0.94
76	59.9821	57.9770	55.9885	-0.92	0.92
77	57.7223	55.8552	53.9998	-0.90	0.89
78	55.5583	53.8210	52.0912	-0.87	0.87
79	53.4856	51.8706	50.2591	-0.85	0.84
80	51.5000	50.0000	48.5000	-0.85	0.84
81	49.7063	48.2057	46.7083	-0.85	0.85
82	47.9835	46.4842	44.9911	-0.89	0.89
83	46.3286	44.8323	43.3452	-0.93	0.92
84	44.7385	43.2468	41.7672	-0.96	0.95
85	43.2105	41.7248	40.2540	-1.00	0.99
86	41.7386	40.2604	38.7996	-1.03	1.02
87	40.3241	38.8545	37.4048	-1.07	1.06
88	38.9643	37.5045	36.0668	-1.11	1.09
89	37.6569	36.2078	34.7831	-1.14	1.13
90	36.3996	34.9622	33.5513	-1.18	1.16
91	35.1903	33.7653	32.3689	-1.22	1.19
92	34.0269	32.6151	31.2338	-1.26	1.23
93	32.9075	31.5096	30.1438	-1.30	1.27
94	31.8302	30.4467	29.0970	-1.33	1.30
95	30.7933	29.4246	28.0915	-1.37	1.34
96	29.7950	28.4417	27.1254	-1.41	1.37
97	28.8337	27.4961	26.1970	-1.45	1.41

98	27.9078	26.5864	25.3048	-1.49	1.44
99	27.0160	25.7110	24.4470	-1.53	1.48
100	26.1569	24.8685	23.6222	-1.57	1.52
101	25.3290	24.0574	22.8291	-1.61	1.55
102	24.5311	23.2765	22.0662	-1.65	1.59
103	23.7620	22.5245	21.3323	-1.69	1.63
104	23.0205	21.8002	20.6261	-1.73	1.66
105	22.3055	21.1025	19.9465	-1.77	1.70
106	21.6159	20.4303	19.2924	-1.81	1.74
107	20.9508	19.7825	18.6626	-1.85	1.77
108	20.3091	19.1582	18.0563	-1.89	1.81
109	19.6899	18.5564	17.4723	-1.93	1.85
110	19.0924	17.9761	16.9098	-1.98	1.89
111	18.5157	17.4166	16.3680	-2.02	1.93
112	17.9590	16.8769	15.8458	-2.06	1.96
113	17.4214	16.3564	15.3427	-2.10	2.00
114	16.9023	15.8542	14.8577	-2.15	2.04
115	16.4010	15.3696	14.3902	-2.19	2.08
116	15.9167	14.9020	13.9394	-2.23	2.12
117	15.4489	14.4506	13.5047	-2.27	2.16
118	14.9968	14.0149	13.0855	-2.32	2.19
119	14.5599	13.5942	12.6811	-2.36	2.23
120	14.1376	13.1879	12.2909	-2.41	2.27
121	13.7294	12.7955	11.9144	-2.45	2.31
122	13.3347	12.4165	11.5510	-2.50	2.35
123	12.9531	12.0503	11.2003	-2.54	2.39
124	12.5840	11.6965	10.8617	-2.58	2.43
125	12.2270	11.3545	10.5348	-2.63	2.47
126	11.8817	11.0240	10.2191	-2.68	2.51
127	11.5475	10.7046	9.9142	-2.72	2.55
128	11.2242	10.3957	9.6197	-2.77	2.59
129	10.9112	10.0970	9.3352	-2.81	2.63
130	10.6084	9.8082	9.0602	-2.86	2.67
131	10.3151	9.5288	8.7945	-2.91	2.71
132	10.0312	9.2586	8.5378	-2.95	2.75
133	9.7563	8.9971	8.2895	-3.00	2.80
134	9.4901	8.7441	8.0495	-3.05	2.84
135	9.2322	8.4993	7.8175	-3.09	2.88
136	8.9824	8.2623	7.5931	-3.14	2.92
137	8.7404	8.0329	7.3760	-3.19	2.96
138	8.5059	7.8108	7.1660	-3.24	3.00
139	8.2787	7.5958	6.9629	-3.29	3.04
140	8.0584	7.3875	6.7664	-3.33	3.09

6. System Configuration

6.1 System Configuration

After the installation and test operation of the room air conditioner have been completed, it should be operated and handled as described below. Every user would like to know the correct method of operation of the room air conditioner, to check if it is capable of cooling (or heating) well, and to know a clever method of using it.In order to meet this expectation of the users, giving sufficient explanations taking enough time can be said to reduce about 80% of the requests for servicing. However good the installation work is and however good the functions are, the customer may blame either the room air conditioner or its installation work because of improper handling. The installation work and handing over of the unit can only be considered to have been completed when its handling has been explained to the user without using technical terms but giving full knowledge of the equipment.

6.2 Instruction

Parts and Functions

Indoor Unit



Actual inlet grille may vary from the one shown in the manual according to the product purchased

Display board for 12:



1. Singal receiver hole
2. COOL display
3. HEAT display
4. TEMP display
5. HEALTH display

(If the unit which you purchased has healthy function,follow it. If not,please ignore.)

6. Dry display
7. TIMER OFF display
   TIMER ON display
   SLEEP display

Display board for 18:



1. Remote signal receiver
2. HEALTH display
3. TIMER OFF display
   TIMER ON display
   SLEEP display
4. TEMP display
5. AUTO display
6. COOL display
7. Dry display
8. HEAT display

Outdoor Unit



① OUTLET
② INLET
③ CONNECTING PIPING AND ELECTRICAL WIRING
④ DRAIN HOSE

Remote controller



1. RESET button
When the remote controller appears abnormal, use a sharp pointed article to press this button to reset the remote controller normal.
2. LIGHT button
Control the lightening and extinguishing of the indoor LED display board.
3. TIMER button
4. CLOCK button
5. SLEEP button
6. MODE button
7. HOUR button
8. HEALTH button
9. ON/OFF button
10. TIMER ON display
11. FAN SPEED display

12. LOCK display
13. SWING UP/DOWN display
14. SLEEP display
15. HEALTH display
16. Operation mode display

Operation mode	AUTO	COOL	DRY	HEAT	FAN
Remote controller					

17. Singal sending display
18. POWER/SOFT display
19. Left/right air flow display
20. TEMP display
21. TIMER OFF display
22. TIMER display
23. TEMP button
24. FAN button
25. HEALTH AIRFLOW button
26. SWING UP/DOWN button
27. SWING LEFT/RIGHT button
28. SET button
29. POWER/SOFT button
30. LOCK button
If pressed, the other buttons will be disabled. Press it once again,lock will be cancelled.
31. CODE button
Use to select CODE A or B which will be displayed on LCD. Please select A without special explanation.

NOTE:
Cooling only unit do not have functions and displays related with heating.

Loading of the battery



1 Remove the battery cover;
2 Load the batteries as illustrated. 2 R-03 batteries, resetting key (cylinder);
3 Be sure that the loading is in line with the " + "/"-";
4 Load the battery,then put on the cover again.

Note:
- The distance between the signal transmission head and the receiver hole should be within 7m without any obstacle as well.
- When electronic-started type fluorescent lamp or change-over type fluorescent lamp or wireless telephone is installed in the room, the receiver is apt to be disturbed in receiving the signals, so the distance to the indoor unit should be shorter.
- Full display or unclear display during operation indicates the batteries have been used up. Please change batteries.
- If the remote controller can't run normally during operation, please remove the batteries and reload several minutes later.

Hint:
Remove the batteries in case unit won't be in usage for a long period. If there are any display after taking-out, just need to press reset key.

Operation

Clock set

Press CLOCK button, "AM" or "PM" flashes.
Press △ or ▽ to set correct time. Each press will increase or decrease 1min. If the button is kept pressed,time will change quickly. After time setting is confirmed,press SET, "AM "and "PM" stop flashing,while clock starts working.

Base Operation



1. Unit start
   Press ON/OFF on the remote controller, unit starts.
2. Select operation mode
   Press MODE button. For each press, operation mode changes as follows:
   Remote controller:

3. Select temp.setting
   Press ▲ / ▼ button
   ▲ Every time the button is pressed, temp.setting increase 2°F,if kept depressed, it will increase rapidly
   ▼ Every time the button is pressed, temp.setting decrease 2°F,if kept depressed, it will decrease rapidly
   Select a desired temperature.
4. Fan speed selection
   Press FAN button. For each press, fan speed changes as follows:
   Remote controller:



Air conditioner is running under displayed fan speed. When FAN is set to AUTO, the air conditioner automatically adjusts the fan speed according to room temperature.

Operation Mode	Display Board	Remote Controller	Note
AUTO			Under the mode of auto operation, air conditioner will automatically select Cool or Heat operation according to room temperature. When FAN is set to AUTO, the air conditioner automatically adjusts the fan speed according to room temperature.
COOL			
DRY			In DRY mode, when room temperature becomes lower than temp.setting about +4 °F,unit will run intermittently at LOW speed regardless of FAN setting.
HEAT			
FAN	nothing		In FAN operation mode, the unit will not operate in COOL or HEAT mode but only in FAN mode ,AUTO is not available in FAN mode.And temp.setting is disabled. In FAN mode,SLEEP operation is not available.

Emergency operation and test operation

- Emergency Operation:
  Use this operation only when the remote controller is defective or lost.
- When the emergency operation switch is pressed, the" Pi "sound is heard once, which means the start of this operation.
- In this operation, the system automatically selects the operation modes, cooling or fan or heat, according to the room temperature.
- When machine is running in emergency, the set value of temperature and wind speed couldn't be altered; meanwhile, it can't operate for dehumidifying or under timing mode.



Test operation:

Test operation switch is the same as emergency switch.

- Use this switch in the test operation when the room temperature is below 60°F, do not use it in the normal operation.
- Continue to press the test operation switch for more than 5 seconds. After you hear the "Pi" sound twice, release your finger from the switch: the cooling operation starts with the air flow speed "Hi".



Air Flow Direction Adjustment

1. Status display of air flow
   Vertical flap



2. Left and right air flow adjustment(manual)
   Move the vertical blade by a knob on air conditioner to adjust left and right direction referring to Fig.



Cautions:

- When adjusting the flap by hand,turn off the unit.
- When humidity is high,condensate water might occur at air outlet if all vertical louvers are adjusted to left or right.
- It is advisable not to keep horizontal flap at downward position for a long time in COOLor DRY mode , otherwise, condensate water might occur.

Note:
When restart after remote turning off, the remote controller will automatically memorize the previous set swing position.

Operation

Sleep Operation

Before going to bed, you can simply press the SLEEP button and unit will operate in SLEEP mode and bring you a sound sleep.

Use of SLEEP function
After the unit starts, set the operation status, then press SLEEP button before which the clock must be adjusted and time being set.

Operation Mode

1. In COOL,DRY mode

1 hours after SLEEP mode starts, temp. will become about 2°F higher than temp.setting. After another 1 hours, temp. rises about 2°F further. The unit will run for further 6 hours then stops Temp. is higher than temp. setting so that room temperature won't be too low for your sleep.



In COOL, DRY mode

2. In HEAT mode
1 hours after SLEEP mode starts, temp will become about 4°F lower than temp. setting. After another 1 hours, temp decrease about 4°F further. After more another 3 hours, temp. rises about 2°F further. The unit will run for further 3 hours then stops. Temp. is lower than temp. setting so that room temperature won't be too high for your sleep.



In HEAT mode

3. In AUTO mode
The unit operates in corresponding sleep mode adapted to the automatically selected operation mode.

4. In FAN mode
It has no SLEEP function.

5. Set the wind speed change when sleeping
If the wind speed is high or middle before setting for the sleep, set for lowing the wind speed after sleeping.
If it is low wind, no change.

6. Note to the power failure resume:
press the sleep button ten times in five seconds and enter this function after hearing four sounds. And press the sleep button ten times within five seconds and leave this function after hearing two sounds.
NOTE:
With the power failure resume, when setting the TIMER ON, TIMER OFF and TIMER ON/OFF, it's memorized as shutdown status when resuming after power out.

POWER/SOFT Operation

(1) POWER Operation

When you need rapid heating or cooling, you can use this function. In COOL mode, fan speed automatically takes high speed of AUTO fan mode. In HEAT mode, fan speed automatically takes medial speed of AUTO fan mode.

(2) SOFT Operation

You can use this function when silence is needed for rest or reading. In SOFT operation mode, fan speed automatically takes low speed of AUTO fan mode.

Note:
During POWER operation, in rapid HEAT or COOL mode, the room will show inhomogeneous temperature distribution. Long period SOFT operation will cause effect of not too cool or not too warm.

To cancel POWER or SOFT operation

Press POWER/SOFT button again, POWER or SOFT disappears.

HEALTH Operation



Healthy Negative ion

The anion generator in the airconditioner can generate a lot of anion effectively balance the quantity of position and anion in the air and also to kill bacteria and speed up the dust sediment in the room and finally clean the air in the room.

Operation

Timer On/Off On-Off Operation

Set clock correctly before starting TIMER operation.
1.After unit starts, select your desired operation mode.
2.Press TIMER button to change TIMER mode. Every time the button is pressed, display changes as follows:
Remote controller:

Then select your desired TIMER mode (TIMER ON or TIMER OFF or TIMER ON-OFF). " ON "or " OFF "will flash.
3.Press HOUR ▲ / ▼ button to set time.
It can be adjusted within 24 hours.
4.After setting correct time, press SET button to confirm " ON "or" OFF " on the remote controller stops flashing.
5.Cancel TIMER mode
Just press TIMER button several times until TIMER mode disappears.
Hints:
After replacing batteries or a power failure happens, time setting should be reset.
Remote controller possesses memory function,when use TIMER mode next time, just press SET button after mode selecting if time setting is the same as previous one.
According to the Time setting sequence of TIMER ON or TIMER OFF, either Start-Stop or Stop-Start can be achieved.

Health airflow Operation

1.Press ON/OFF to starting
Setting the comfort work conditions.
2.The setting of health airflow function
1).Press the button of health airflow， appears on the display. Horizontal airflow sending. Avoid the strong airflow blows direct to the body.
2).Press the button of health airflow again, appears on the display. Downward airflow sending. Avoid the strong airflow blows direct to the body.
3.The cancel of the health airflow function
Press the button of health airflow again, the unit goes on working under the condition before the setting of health airflow function.
Notice: Cannot pull direct the flap by hand. Otherwise, the grille will run incorrectly. If the grille is not run correctly, stop for a minute and then start, adjusting by remote controller.
Note:
1.After setting the health airflow function, the position grill is fixed.
2.In heating, it is better to select the mode.
3.In cooling, it is better to select the mode.
4.In cooling and dry, using the air conditioner for a long time under the high air humidity, a phenomenon falling drips of water occurs at the grille .

IMPORTANT INFORMATION REGARDING THE REFRIGERANT USED



This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent into the atmosphere.
Refrigerant type:R410A
GWP* value:1975
GWP=global warming potential
Please fill in with indelible ink,
• 1 the factory refrigerant charge of the product
• 2 the additional refrigerant amount charged in the field and
• 1+2 the total refrigerant charge
on the refrigerant charge label supplied with the product.
The filled out label must be adhered in the proximity of the product charging port (e.g. onto the inside of the stop value cover).
A contains fluorinated greenhouse gases covered by the Kyoto Protocol
B factory refrigerant charge of the product: see unit name plate
C additional refrigerant amount charged in the field
D total refrigerant charge
E outdoor unit
F refrigerant cylinder and manifold for charging

Maintenance

For Smart Use of The Air Conditioner

Setting of proper room temperature



Do not block the air inlet or outlet



Close doors and windows during operation



Use the timer effectively



If the unit is not to be used for a long time, turn off the power supply main switch.

Use the louvers effectively

Remote Controller

Do not use water , wipe the controller with a dry cloth.Do not use glass cleaner or chemical cloth.

Indoor Body



Wipe the air conditioner by using a soft and dry cloth.For serious stains,use a neutral detergent diluted with water.Wring the water out of the cloth before wiping.then wipe off the detergent completely.

Do not use the following for cleaning

Gasoline,benzine, thinner or cleanser may damage the coating of the unit.

Hot water over 40°C(104°F) may cause discoloring or deformation.

Air Filter cleaning

1 Open the inlet grille by pulling it upward.

2 Remove the filter.
Push up the filter's center tab slightly until it is released from the stopper, and remove the filter downward.

3 Clean the filter.
Use a vacuum cleaner to remove dust, or wash the filter with water.After washing, dry the filter completely in the shade.

4 Attach the filter.
Attach the filter correctly so that the "FRONT" indication is facing to the front.Make sure that the filter is completely fixed behind the stopper.If the right and left filters are not attached correctly, that may cause defects.

5 Close the inlet grille.





Replacement of Air Purifying Filter

1.Open the Inlet Grille

Prop up the inlet grille by using a small device named grille-support which located in the right side of the indoor unit.



2.Detach the standard air filter

Slide the knob slightly upward to release the filter, then withdraw it.



3.Attach Air Purifying Filter

Put air purifying filter appliances into the right and left filter frames.



4.Attach the standard air filter

(Necessary installation)



ATTENTION:

The white side of the photocatalyst air purifying filter face outside,and the black side face the unit.

The green side of the bacteria-killing medium air purifying filter face outside,and the white side face the unit.

5.Close the Inlet Grille

Close the Grille surely

NOTE:

- The photocatalyst air purifying filter will be solarized in fixed time. In normal family, it will be solarized every 6 months.
- The bacteria-killing medium air purifying filter will be used for a long time,no need for replacement. But in the period of using them ,you should remove the dust frequently by using vacuum cleaner or flaping them lightly,otherwise , its performance will be affected.
- Please keep the bacteria-killing medium air purifying filter in the cool and dry conditions avoid long time directly sunshine when you stop using it,or its ability of sterilization will be reduced.

Cautions

⚠ WARNING

Please call Sales/Service Shop for the Installation.
Do not attempt to install the air conditioner by yourself because improper works may cause electric shock, fire, water leakage.

⚠ WARNING

When abnormality such as burnt-small found, immediately stop the operation button and contact sales shop.



STRICT ENFORCEMENT

Use an exclusive power source with a circuit breaker



Check proper installation of the drainage securely

STRICT ENFORCEMENT



Connect power supply cord to the outlet completely

STRICT ENFORCEMENT

Use the proper voltage

STRICT ENFORCEMENT

1.Do not use power supply cord extended or connected in halfway
2.Do not install in the place where there is any possibility of inflammable gas leakage around the unit.
3.Do not get the unit exposed to vapor or oil steam.

PROHIBITION

Do not use power supply cord in a bundle.



PROHIBITION

Take care not to damage the power supply cord.



PROHIBITION

Do not insert objects into the air inlet or outlet.



PROHIBITION

Do not start or stop the operation by disconnecting the power supply cord and so on.



PROHIBITION

Do not channel the air flow directly at people, especially at infants or the aged.



PROHIBITION

Do not try to repair or reconstruct by yourself.



Connect the earth cable.



⚠ CAUTION

Do not use for the purpose of storage of food, art work, precise equipment, breeding, or cultivation.



PROHIBITION

Take fresh air occasionally especially when gas appliance is running at the same time.



STRICT ENFORCEMENT

Do not operate the switch with wet hand.



PROHIBITION

Do not install the unit near a fireplace or other heating apparatus.



PROHIBITION

Check good condition of the installation stand



PROHIBITION

Do not pour water onto the unit for cleaning



PROHIBITION

Do not place animals or plants in the direct path of the air flow



PROHIBITION

Do not place any objects on or climb on the unit.



PROHIBITION

Do not place flower vase or water containers on the top of the unit.

PROHIBITION



Trouble shooting

Before asking for service, check the following first.

	Phenomenon	Cause or check points
Normal Performance inspection	The system does not restart immediately.	• When unit is stopped, it won't restart immediately until 3 minutes have elapsed to protect the system. • When the electric plug is pulled out and reinserted, the protection circuit will work for 3 minutes to protect the air conditioner.
	Noise is heard	• During unit operation or at stop, a swishing or gurgling noise may be heard.At first 2-3 minutes after unit start, this noise is more noticeable. (This noise is generated by refrigerant flowing in the system.) • During unit operation, a cracking noise may be heard.This noise is generated by the casing expanding or shrinking because of temperature changes. • Should there be a big noise from air flow in unit operation, air filter may be too dirty.
	Smells are generated.	• This is because the system circulates smells from the interior air such as the smell of furniture, paint, cigarettes.
	Mist or steam are blown out.	• During COOL or DRY operation, indoor unit may blow out mist. This is due to the sudden cooling of indoor air.
	In dry mode, fan speed can't be changed.	• In DRY mode, when room temperature becomeslower than temp. setting+3.6°F,unit will run intermittently at LOW speed regardless of FAN setting.
Multiple check		• Is power plug inserted? • Is there a power failure? • Is fuse blownout?
	Poor cooling	• Is the air filter dirty? Normally it should be cleaned every 15 days. • Are there any obstacles before inlet and outlet? • Is temperature set correctly? • Are there some doors or windows left open? • Is there any direct sunlight through the window during the cooling operation?(Use curtain) • Are there too much heat sources or too many people in the room during cooling operation?

Cautions

- Do not obstruct or cover the ventilation grille of the air conditoner.Do not put fingers or any other things into the inlet/outlet and swing louver.
- Do not allow children to play with the air conditioner.In no case should children be allowed to sit on the outdoor unit.

Specifications

- The refrigerating circuit is leak-proof.

The machine is adaptive in following situation

1.Applicable ambient temperature range:

Cooling	Indoor	Maximum:D.B/W.B	32°C/23°C
		Minimum:D.B/W.B	21°C/15°C
	Outdoor	Maximum:D.B/W.B	43°C/26°C
		Minimum: D.B	18°C
Heating	Indoor	Maximum:D.B	27°C
		Minimum: D.B	0°C
	Outdoor	Maximum:D.B/W.B	24°C/18°C
		Minimum:D.B/W.B	-7°C/-8°C
	Outdoor (INVERTER)	Maximum:D.B/W.B	24°C/18°C
		Minimum:D.B	-15°C

2. If the power supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person.
3. If the fuse of indoor unit on PC board is broken,please change it with the type of T. 3.15A/ 250V. If the fuse of outdoor unit is broken,change it with the type of T.25A/250V
4. The wiring method should be in line with the local wiring standard.
5. After installation, the power plug should be easily reached.
6. The waste battery should be disposed properly.
7. The appliance is not intended for use by young children or infirm persons without supervision.
8. Young children should be supervised to ensure that they do not play with the appliance.
9. Please employ the proper power plug, which fit into the power supply cord.
10. A breaker should be incorporated into fixed wiring. The breaker should be all-pole switch and the distance between its two contacts should be not less than 3mm.
11. The power plug and connecting cable must have acquired the local attestation.
12. In order to protect the units,please turn off the A/C first, and at least 30 seconds later, cutting off the power.

7 Service Diagnosis

7.1 Caution for Diagnosis

The operation lamp flashes when any of the following errors is detected.

1.When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.

2.When a signal transmission error occurs between the indoor and outdoor units.In either case, conduct the diagnostic procedure described in the following pages.

7.2.Problem Symptoms and Measures

Symptom	**Check Item**	**Details of Measure**
None of the units operates	Check the power supply.	Check to make sure that the rated voltage is supplied.
	Check the indoor PCB	Check to make sure that the indoor PCB is broken
Operation sometimes stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation.
Equipment operates but does not cool, or does not heat (only for heat pump)	Check for faulty operation of the electronic expansion valve.	Set the units to cooling operation, and compare the temperatures of the liquid side connection pipes of the connection section among rooms to check the opening and closing operation of the electronic expansion valves of the individual units.
	Diagnosis by service port pressure and operating current.	Check for insufficient gas.
Large operating noise and vibrations	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Technical Guide, etc.) are provided.

7.3.Error Codes and Description indoor display

	Code indication		Description	Reference Page
	indoor	Outdoor (LED1 flash times)		
Indoorand Outdoor	E7	15	Communication fault between indoor and outdoor units	Page .59
Indoor Malfunction	E1		Room temperature sensor failure	Page .51
	E2		Heat-exchange sensor failure	Page .51
	E4		Indoor EEPROM error	Page .58
	E14		Indoor fan motor malfunction	Page .52
Outdoor Malfunction		1	Outdoor EEPROM error	Page .58
		2	The protection of IPM	Page .53
		3	Overcurrent protection of AC electricity for the outdoor model	
		4	Communication fault between the IPM and outdoor PCB	Page 55
		6	Power voltage is too high or low	Page .61
		8	Overheat protection for exhaust temperature	Page .57
		9	outdoor fan motor malfunction	
		10	Frost-removing temperature sensor failure	Page .56
		11	SUCK temperature sensor failure	Page .56
		12	Ambient temperature sensor failure	Page .56
		13	Exhaust temperature sensor failure	Page .56
		18	deviate from the normal for the compressor	Page .62
		19	Loop of the station detect error	Page .62
		24	Overcurrent of the compressor	Page .63
		25	Overcurrent protection for single-phase of the compressor	Page .63

7.3.1Thermistor or Related Abnormality (indoor unit)

Indoor Display	**E1**: Room temperature sensor failure **E2**: Heat-exchange sensor failure
Method of Malfunction Detection	the temperatures detected by the thermistors are used to determine thermistor errors
Malfunction Decision Conditions	when the thermistor input is more than 4.92V or less than 0.08V during compressor operation. * **Note:** The values vary slightly in some models
Supposed Causes	■ Faulty connector connection ■ Faulty thermistor ■ Faulty PCB

Troubleshooting * **Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.



Thermistor resistance check method:

Remove the connector of the thermistor on the PCB, and measure the resistance of thermistor using tester.The relationship between normal temperature and resistance is shown in the value of indoor thermistor.



7.3.2 Indoor fan motor malfunction

Indoor Display	**E14**
Method of Malfunction Detection	The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation
Malfunction Decision Conditions	when the detected rotation feedback singal don't receiced in 2 minutes

Supposed Causes
- ■ Operation halt due to breaking of wire inside the fan motor .
- ■ Operation halt due to breaking of the fan motor lead wires
- ■ Detection error due to faulty indoor unit PCB

How to check Fan Motor (DC)

1. Check connector connection.
2. Check motor power supply voltage output (pins 1-4).
3. Check motor control voltage (pins 4-5).
4. Check rotation command voltage output (pins 4-6).
5. Check rotation pulse input (pins 4-7).



Notes:the a/c is electrifying,don't pull out or insert the terminals of the motor,else the motor would be damaged

Troubleshooting * Caution Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.

Turn off power supply and rotate fan by hand



7.3.3 IPM protection

outdoor display LED1 flash 2 times: **Indoor Display F1**

Method of Malfunction Detection

IPM protection is detected by checking the compressor running condition and so on.

Malfunction Decision Conditions

- The system leads to IPM protection due to over current
- The compressor faulty leads to IPM protection
- circuit component of IPM is broken and led to IPM protection

Supposed Causes

- IPM protection dues to the compressor faulty
- IPM protection dues to faulty PCB of IPM module
- Compressor wiring disconnected

Troubleshooting

*** Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.



Check the IPM module method:

Disconnect the compressor harness connector from the outdoor unit PCB.
To disengage the connector, press the protrusion on the connector.
Then, to measure resistance between P (+) andN (-) and the U, V and W terminals of the compressor connector with a multi-tester. Evaluate the measurement results for a pass/fail judgment.

N(-)terminal of tester(P(+)for digital tester)	P(+)	UVW	P(-)	UVW
P(+)terminal of tester(N(-)for digital tester)	UVW	P(+)	UVW	P(-)
Normal resistance	Several kΩ to several MΩ (*)			
Unacceptable resistance	Short (0 Ω) or open			

7.3.4 The IPM and outdoor PCB don't communicate or Related Abnormality

outdoor display	LED1 flash 4 times Indoor Display F3
Method of Malfunction Detection	Communication is detected by checking the IPM module and the outdoor PCB
Malfunction Decision Conditions	■ The outdoor PCB broken leads to communication fault ■ The IPM module broken leads to communication fault
Supposed Causes	■ The outdoor PCB is broken ■ The IPM module is broken ■ Communication wiring disconnected

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.


1) Check whether Terminal CN23 and CN22 on the outdoor mainboard CN10 and CN11 on IPM module
2) Check whether the connected wire between IPM and outdoor
Are they good?
NO
1) Pull out and reinsert the terminals.
2) Replace connected wire
YES
Electrify the machine again and turn it on, Check whether the voltage between 1 and 2 of Terminal CN22is about DC5V, Check whether the voltage between2 and 3 of Terminal CN22 is about DC15V
YES
Replace the outdoor IPM module with a new one.
NO
Replace the outdoor mainboard with a new one

7.3.5 Thermistor or Related Abnormality(outdoor unit)

Frost-removing temperature sensor failure

Indoor display: **F21**
outdoor display: LED1 flash 10 times:

Exhaust temperature sensor failure
Indoor display: **F25**
outdoor display: LED1 flash 13 times:

Ambient temperature sensor failure
Indoor display: **F6**
outdoor display: LED1 flash 12 times:

Suck temperature sensor failure
Indoor display: **F7**
outdoor display: LED1 flash 11times:

Method of Malfunction Detection This type of error is detected by checking the thermistor input voltage to the microcomputer. (A thermistor error is detected by checking the temperature)

Malfunction Decision Conditions The thermistor input is above 4.9V or below 0.1V with the power on.

*** Note:** The values may vary slightly in some models

Supposed Causes
- ■ Faulty connector connection
- ■ Faulty thermistor
- ■ Faulty PCB

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.



7.3.6 Overheat Protection For Exhaust Temperature

Indoor display **outdoor display**	**F4** LED1 flash 8 times
Method of Malfunction Detection	the exhaust temperature control is checked with the temperature being detected by the exhaust pipe thermistor
Malfunction Decision Conditions	when the compressor discharge temperature is above 117℃
Supposed Causes	■ Electronic expansion valve defective ■ Faulty thermistor ■ Faulty PCB

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.


Electrify the machine again and turn it on with the remote controller, then measure the temperature at the exhaust temperature sensor of the compressor on the outdoor unit
the temperature exceeds 110℃ shortly after the machine
YES
1) The cryogen may have been leaked during installation, or there may be leakage in the piping system.
2) There may be other causes to make the exhaust temperature too high.
NO
Measure the temperature at the exhaust temperature sensor of the compressor on the outdoor unit
Malfunctions occur after running for some time? even though the asured temperature is below 117℃.
YES
Exhaust temperature sensor is broken and needs be replaced
NO


Pull out the exhaust sensor and measure its resistance at standard temperatures according to the resistance-temperature table
NO
The sensor is damaged. Replace the sensor with a new one.
YES
the results deviate much?
YES
The sensor is damaged. Replace the sensor with a new one.
NO
The outdoor mainboard is damaged and needs be replaced

7.3.7 The EEPROM Abnormality (Indoor or outdoor unit)

Indoor Display **E4**: ：Indoor EEPROM error
F12：Outdoor EEPROM error

Method of Malfunction Detection the Data detected by the EEPROM are used to determine MCU

Malfunction Decision Conditions when the Data of EEPROM is error or the EEPROM is damaged

Supposed Causes
- ■ Faulty EEPROM data
- ■ Faulty EEPROM
- ■ Faulty PCB

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.


Check whether LED1 on the outdoor unit blinks 1 times
YES
The outdoor mainboard is damaged. Replace it with a new one.
NO
the indoor mainboard is damaged, and needs replacing with a new one

7.3.8 Communication error between the indoor and outdoor units

Indoor display **E7**：
Outdoor: **display**： LED1 flash 15 times

Method of Malfunction Detection The date received from the another unit in indoor unit-outdoor unit signal transmission is checked whether is normal

Malfunction Decision Conditions When the date sent from the another unit cannot be received normally,or when the content of the data is abnormal

Supposed Causes
- ■ indoor unit- outdoor unit signal transmission error due to wiring error
- ■ Faulty PCB

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.


Restart the a/c and it becomes normally.
Yes
The outdoor mainboard needs dehumidification.
NO
If starting up normally, but malfunction occurs again after a while
Yes
The outdoor mainboard needs dedust.
No
Check whether the linking cable between the indoor and outdoor is well connected or whether its core wires are well insulated.
No
1. Reconnect the linking cable;
2. Replace the linking cable with new one.
Yes
（A）


（A）
Check the status of LED1 on the indoor mainboard. If the LED1 blinks
Yes
No
measure the voltage between Jumpers 3 and 4 of IC8 on the indoor mainboard with a multimeter.
Test the outdoor power supply (230VAC and +310VDC) with a multimeter.
If the voltage is of a constant value of 0V DCto5V DC
If 230VAC is available but 310DC not, the power module is damaged, replace it with a new one.
Yes
NO
If both 230VAC and 310DC are available, measure +12V(from7805)is available.
The indoor mainboard is damaged; replace it with a new one.
NO
The outdoor mainboard is damaged; Replace them with a new one.
YES
If the LED1 is off within two minutes after the machine is supplied with power, measure the AC voltage between positions 1 and 3 on the terminal of outdoor unit with a multimeter.
If the value is constant at about 30V, the indoor mainboard is damaged, replace it with a new one.
If the value varies between 0 and 80 VAC, the outdoor mainboard is damaged, replace it with a new one.
The outdoor mainboard is damaged; replace it with a new one.

7.3.10 Power Supply Over or under voltagve fault

Indoor display
outdoor display: **F19**
LED1 flash 6 times

Method of circuit.
Malfunction Detection An abnormal voltage rise or fall is detected by checking the specified voltage detection

Malfunction Decision Conditions An voltage signal is fed from the voltage detection circuit to the microcomputer

Supposed Causes
- Supply voltage not as specified
- the IPM module is broken
- the outdoor PCB is broken

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or else parts damage may be occurred.



About how to check the IPM module,please refer to IPM protection fault

7.3.11 Loop of the station detect error

Outdoor Display LED1 flash 18 times **Indoor Display** **F11**

LED1 flash 19 times **Indoor Display** **F28**

Method of Malfunction Detection the position of the compressor rotor can not detected normally

Malfunction Decision Conditions when the The wiring of compressor is wrong or the connection is poor; **or** the compressor is damaged

Supposed Causes
- ■ Faulty The wiring of compressor
- ■ Faulty compressor
- ■ Faulty PCB

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.


Within 3 minutes after the machine is supplied with power and turned on with the remote controller, the compressor couldnot stard up
YES
1. The wiring of compressor is incorrect or the connection is poor;
2. The compressor is damaged
NO
At frist, the compressor start up ,soon the compressor stopped with the LED1 on the outdoor PCB blinks（1Hz）for 19 times
YES
IPM Module is damaged and needs replacing.
Malfunction unsolved
the Malfunctions exist also, . The compressor is damaged replace a new one

7.3.12 Over-current of the compressor

Outdoor Display LED1 flash 3 or 24 or 25 times

Method of Malfunction Detection The current of the compressor is too high

Malfunction Decision Conditions when the IPM Module is damaged
or the compressor is damaged
power supply. voltage is too low or too high

Supposed Causes
- ■ Faulty IPM Module
- ■ Faulty compressor
- ■ Faulty power supply

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.


Electrify the machine again and turn it on with the remote controller,If malfunctions are reported before or upon the compressor being started up,
Yes
IPM Module is damaged and needs replacing.
No
The compressor is started normally, but malfunctions are reported after it has run for some time. Check the power supply. If the voltage is too low or too high
Yes
Repair the power supply

7.3.13Fan Motor(DC Motor) or Related Abnormality

Indoor Display	LED1 flash 9 times
Method of determine Malfunction Detection	The rotation speed detected by the Hall IC during fan motor operation is used to abnormal fan motor operation
Malfunction Decision Conditions	when the detected rotation feedback singal don't receiced in 2 minutes
Supposed Causes	■ Operation halt due to short circuit inside the fan motor winding. ■ Operation halt due to breaking of wire inside the fan motor . ■ Operation halt due to breaking of the fan motor lead wires ■ Dedection error due to faulty indoor unit PCB

How to check Fan Motor (DC)

1. Check connector connection.
2. Check motor power supply voltage output (pins 4-7).
3. Check motor control voltage (pins 4-3).
4. Check rotation command voltage output (pins 4-1).
5. Check rotation pulse input (pins 4-2).


7 ⟶ M0tor power supply voltage
6 Unused
5 Unused
4 ⟶ P.0V (reference potential)
3 ⟶ Motor control voltage(15 VDC)
2 ⟵ Rotation pulse input
1 ⟶ Rotation command voleage(1~7 VDC)

Notes:the a/c is electrifying,don't pull out or insert the terminals of the motor,else the motor would be damaged

Troubleshooting *** Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.


Turn off power supply and rotate fan by hand
Does fan rotate smoothly?
NO
Replace the motor
Yes
Turn power ON and operate fan
Does it rotate?
NO
Turn off power supply and disconnect fan motor connector.then turn power ON
Check output of fan motor connector
Is motor power voltage DC310V gengerated?
NO
Replace indoor unit PCB
Yes
Stop fan motor
Check output of fan motor connector
Is motor control power voltageDC15Vgenerated?
NO
Replace indoor unit PCB
Yes
Is rotation number command pulse generated?
Is rotation number commamd voltage DC1～6V
Yes
Replace fan motor
No
Replace indoor unit PCB
No
Replace indoor unit PCB

Installation Manual of Room Air Conditioner

Preparation

Necessary Tools for Installation

- Hammer
- Nipper
- Hacksaw
- Hole core drill
- Spanner(17,19 and 26mm)
- Gas leakage detector or soap-and-water solution
- Torque wrench (17mm,22mm,26mm)
- Pipe cutter
- Flaring tool
- Knife
- Measuring tape
- Reamer

Power Source

- Before inserting power plug into receptacle, check the voltage without fail. The power source is the same as the corresponding name plate.
- Install an exclusive branch circuit of the power.
- A receptacle shall be set up in a distance where the power cable can be reached. Do not extend the cable by cutting it.

Selection of Installation Place

Indoor Unit - Select a location that is

- Robust not causing vibration, where the body can be supported sufficiently.
- Not affected by heat or steam generated in the vicinity, where inlet and outlet of the unit are not disturbed.
- Possible to drain easily, where piping can be connected with the outdoor unit.
- Where cold air can be spread in a room evenly.
- Nearby a power receptacle. (Refer to drawings).
- Place where the distance of more than lm from televisions, radios, wireless apparatuses and fluorescent lamps can be left.
- In the case of fixing the remote controller on a wall, place where the indoor unit can receive signals when the fluorescent lamps in the room are in use.

Outdoor Unit - Select a location that is

- Less affected by rain or direct sunlight and is sufficiently ventilated.
- Strong enough to bear the unit, where vibration and noise are not increased.
- Not causing a nuisance to neighbors due to discharged air or noise.
- A distance marked ? is available as illustrated in the below figure.

Drawing for the installation of indoor and outdoor units

The models adopt HCFC free refrigerant R410A



Optional parts for piping

- (A) Non-adhesive tape
- (B) Adhesive tape
- (C) Saddle (L.S) with screws
- (D) Connecting electric cable for indoor and outdoor
- (E) Drain hose
- (F) Heating insulating material
- (G) Piping hole cover

Floor fixing dimensions of the outdoor unit (Unit:mm / inch)

Fixing of outdoor unit

- Fix the unit to concrete or block with bolts (10mm) and nuts firmly and horizontally.
- When fitting the unit to wall surface, roof or rooftop, fix a supporter securely with nails or wires in consideration of earthquake and strong wind.
- If vibration may affect the house, fix the unit by attaching a vibration-proof mat.

- The marks from (A) to (G) in the figure are the parts numbers.
- The distance between the indoor unit and the floor should be more than 2m.

The above picture is for your reference only. Your product may look different.
Read this manual before installation.
Explain the operation of the unit to the user according to this manual.

NO.0010536242

Accessory parts	
Remote controller (1)	Drain hose (1)
AAA dry battery (2)	Cushion (4)
Mounting plate (1)	Drain-elbow (1)
Plastic cap (4) Ø4X25 Screw (4)	Pipe supporting plate (1)

Selection of pipe

Type	For 09K 12K	For 18K	For 24K
Liquid pipe (Ø)	6.35mm(1/4")	6.35mm(1/4")	9.52mm(3/8")
Gas pipe (Ø)	9.52mm(3/8")	12.7mm(1/2")	15.88mm(5/8")

NOTE：The thickness of the pipe must be 0.8mm(1/16") at least.

Indoor unit

1 Fitting of the Mounting Plate and Positioning of the wall Hole

When the mounting plate is first fixed

1. Carry out, based on the wall studs or lintels, a proper leveling for the plate to be fixed against the wall, then temporarily fasten the plate with one steel nail.
2. Make sure once more the proper level of the plate, by hanging a thread with a weight from the central top of the plate, then fasten the plate.
3. Find the wall hole location A using a measuring tape



2 Making a Hole on the Wall and Fitting the Piping Hole Cover

- Make a hole of 70mm (2 3/4) in diameter, slightly descending to outside the wall.
- Install piping hole cover and seal it off with putty after installation



3 Installation of the Indoor Unit

Drawing of pipe

[Rear piping]

- Draw pipes and the drain hose, then fasten them with the adhesive tape

[Left· Left-rear piping]

- In case of left side piping, cut away, with a nipper, the lid for left piping.
- In case of left-rear piping, bend the pipes according to the piping direction to the mark of hole for left-rear piping which is marked on heat insulation materials.

1. Insert the drain hose into the carity of heat insulation materials of indoor unit.
2. Insert the indoor/outdoor electric cable from backside of indoor unit, and pull it out on the front side, then connect them.
3. Coat the flaring seal face with refrigerant oil and connect pipes. Cover the connection part with heat insulation materials, cover with adhesive tape.





- Indoor/outdoor electric cable and drain hose must be bound with refrigerant piping with protecting tape.

[Other piping direction]

- Cut away, with a nipper, the lid for piping according to the piping direction and then bend the pipe according to the position of wall hole. When bending, be careful not to crush pipes.
- Connect beforehand the indoor/outdoor electric cable, and then pull out the connected to the heat insulation of connecting part specially.

Fixing the indoor unit body

- Hang the unit body securely onto the upper notches of the mounting plate. Move the body from side to side to verify its secure fixing.
- In order to fix the body onto the mounting plate,hold up the body at a slant from the underside and then put it down perpendicularly.



Unloading of indoor unit body

- When you unload the indoor unit, please use your hand to raise the body, then lift the bottom of the body outward slightly and lift the unit until it leaves the mounting plate.



4 Connecting the indoor/outdoor Electric Cable

Removing the wiring cover

- Remove terminal cover at right bottom corner of indoor unit, then take off wiring cover by removing its screws.

When connecting the cable after installing the indoor unit

1. Insert from outside the room cable into left side of the wall hole, in which the pipe has already existed.
2. Pull out the cable on the front side, and connect the cable making a loop.

When connecting the cable before installing the indoor unit

- Insert the cord from the back side of the unit, then pull it out on the front side.
- Fasten the unit wire harness to the conduit holder using the lock nut.
- Position the conduit holder to its original state using screw.



Note When connecting the cable, confirm the terminal number of indoor and outdoor units carefully. If wiring is not correct, improper operation may occur and cause damage to the units.



HSU09VHJ(DB)-W Power cable: ⩾ 2wire with ground 16AWG
HSU12VHJ(DB)-W Power cable: ⩾ 2wire with ground 16AWG
HSU18VHJ(DB)-W Power cable: ⩾ 2wire with ground 12AWG
HSU24VHJ(DB)-W Power cable: ⩾ 2wire with ground 12AWG

All models: Control cable: 4wire, 18AWG



HSU09XCK-W Power cable: ⩾ 2wire with ground 16AWG
HSU12XCK-W Power cable: ⩾ 2wire with ground 16AWG

1. If the fuse on PC board is broken please change it with the type of T. 3.15A/250V(indoor unit),25A/250V(outdoor unit).
2. The wiring method should be in line with the local wiring standard.
3. After installation, the power plug should be easily reached.
4. A breaker should be incorporated into fixed wiring. The breaker should be all-pole switch.

Outdoor unit

1 Installation of Outdoor Unit

Install according to Drawing for the installation of indoor and outdoor units

2 Connection of pipes

- To bend a pipe, be careful not to crush the pipe, and the bending radius should be 30 (1 1/6) to 40 mm (1 4/7) or longer.
- Connecting the pipe of gas side first makes working easier.
- The connection pipe is specialized for R410A.

Half union Flare nut



Spanner Torque wrench

Forced fastening without careful centering may damage the threads and cause a leakage of gas.

Pipe Diameter(ø)	Fastening torque
Liquid side6.35mm(1/4")	18N.m/13.3Ft.lbs
Liquid/Gas side9.52mm(3/8")	42 N.m/30.1Ft.lbs
Gas side 12.7mm(1/2")	55N.m/40.6Ft.lbs
Gas side 15.88mm(5/8")	60 N.m/44.3Ft.lbs

Ensure that no dirt or debris enters the pipe.

The standard pipe length is 7m (27 9/16). If it is over 7m (27 9/16), the function of the unit will be affected. If the pipe has to be lengthened, the refrigerant should be charged, according to 20 g/m (0.018 oz/inch). But the charge of refrigerant must be conducted by professional air conditioner servicer. Before adding additional refrigerant, perform air purging from the refrigerant pipes and indoor unit using a vacuum pump,then charge additional refrigerant.



- Max.Elevation: Amax=10m
- In case the elevation A is more than 5m, oil trap shoud be installed every 5~7m
- Max. Length: Bmax=15m
- In case the pipe length B is more than 10m, the refrigerant should be charged, according to 20 g/m.

3 Connection

- Take off the panel(top), by removing the 5 screws.
- Remove the plugs on the conduit plate.
- Temporarily mount the conduit tubes on the conduit plate.
- Connect both the power supply and unit wire harness to the corresponding terminals on the terminal board.
- Ground the unit in accordance with local codes.
- Allow several extra inches of wire for making wiring connections.
- Use lock nuts to secure conduit tubes.



4 Attaching Drain-Elbow

- If the drain-elbow is used, please attach it as figure. (Note: Only for heat pump unit.)

5 Purging Method:To use vacuum pump

1. Remove the service port cap of the 3-way valve and the valve stem cap for both valves. Connect the low pressure hose from the manifold set to the 3-way valve. Connect the center hose to the vacuum pump.
2. Open the handle on low side of manifold and operate vacuum pump. If the low side gauge reaches a vacuum immediately, ensure the hoses are connected properly and the low side manifold handle is open.
3. Vacuum for a minimum of 15 minutes and check the gauge for a proper vacuum. After the completion of vacuuming, close the handle 'Lo' in gaugemanifold and stop the operation of the vacuum pump. Leave the hoses connected and check the vacuum level again in 1-2 minutes. If you lose the vacuum, ensure all connections are tight and flare the tubes again if needed.
4. Open the valve rod stem the 2-way valve counterclockwise to 90 degrees. After 6 seconds, close the 2-way valve and inspect for gas leakage.

5. No gas leakage?

In case of gas leakage, tighten parts of pipe connection. If leakage stops, then proceed

6. Detach the charge hose from the service port, open 2-way valve and 3-way. Turn

7. To prevent the gas leakage,

8. After attaching each cap, check for gas leakage around the caps.



CAUTION

- If the refrigerant of the air conditioner leaks, it is necessary to discharge all the refrigerant. Vacuum first, then charge the liquid refrigerant into air conditioner according to the amount marked on the name plate.
- Please do not let other cooling medium, except specified one (R410A), or air enter into the cooling circulation system. Otherwise, there will be abnormal high pressure in the system casuing damage and possibly personal injuries.

- The power source must be exclusively used for air conditioner. (Over I0A)
- In the case of installing an air conditioner in a moist place, please install an earth leakage breaker (GFCI).
- For installation in other places, use a circuit breaker as far as possible.

2 Cutting and Flaring Work of Piping

- Pipe cutting is carried out with a pipe cutter and burs must be removed.
- After inserting the flare nut, flaring work is carried out.

	Flare tool for R410A	Conventional flare tool	
	Clutch-type	clutch-type(Rigid-type)	Wing-nut type (Imperial-type)
A	0~0.5mm	1.0~1.5mm	1.5~2.0mm



3 On Drainage

- Please install the drain hose so as to be downward slope without fail.
- Please don't do the drainage as shown below.


It becomes high midway.
The end is immersed in water.
It waves.
Less than 5cm
The gap with the ground is too small.
There is the bad smell from a ditch

- Please pour water in the drain pan of the indoor unit, and confirm that drainage is carried out surely to outdoor.
- In case that the attached drain hose is in a room, please apply heat insulation to it without fail.



■ Check for Installation and Test Run

■ Please kindly explain to our customers how to operate through the instruction manual.

Check Items for Test Run

□ Put check mark ✓ in boxes

- □Gas leak from connecting pipe?
- □Heat insulation of
- □Are the connecting wirings of indoor and outdoor firmly inserted to the terminal block?
- □Is the connecting wiring of indoor and outdoor firmly fixed?
- □Is drainage securely carried out?
- □Is the ground wire securely connected?
- □Is the indoor unit securely fixed?
- □Is power source voltage abided by the code?
- □Is there any noise?
- □Is the lamp normally lighting?
- □Are cooling and heating (when in heat pump) performed normally?
- □Is the operation of room temperature regulator normal?

4

9. Removal Procedure

Indoor unit

9.1 Removal of Air Filter

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Features		
2. Remove the air filters.		
1	Hold the front panel by the tabs on the both sides and lift it until it stops with a click. 	

9.2 Removal of Front Grille

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the front panel.		
1 Open the front panel to the horizontal position. Release the both sides pivots and remove the front panel.		■ Start the removal procedure of front grille when the panels are closed. ■ Slide the front panel side to side to release each axis. ■ When assembling, align the right and left axes with grooves in turn and insert them to the end.

9.3 Removal of Horizontal Blade

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the horizontal blade.		■ The horizontal blade is single.
1 Release the center pivot.	 	■ Installation procedure 1. Since key pattern hook is provided, rotate the blade and fit it to the left pivot first. 2. Fit the blade to the right pivot. 3. Fit the blade to the center pivot.
2 Bend the horizontal blade slightly and remove it.		

Step	Procedure		Points
	Pull the two bolt dowels and Loosen the marked two screws		■ When assembling, install the front grille horizontally so as not to stuff the flap inside. ■ When assembling, make sure the three hooks are caught properly.
	Pull the air filters and removel them		

Step	Procedure		Points
	Release the marked three hooks.		
	Pull the front grille out horizontally and remove it.		■ When assembling, install the front grille horizontally so as not to stuff the flap inside. ■ When assembling, make sure the three hooks are caught properly.

9.4 Removal of Drain pan

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the Drain pan		
1	Loosen the marked screws	
2	Pull the two chips out from the frame	
3	Pull out the drain pan	







9.5 Removal of Vertical Blades and Swing Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
■ Remove the assembly of the outlet grille.		
1. Remove the vertical blades.		
1	Push the hooks on the back of the vertical blades and remove.	











9.6 Removal of Electrical Box

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
■ Remove the front grille.		■ Discharge the static electricity from your body before touching the electrical parts like signal receiver PCB. It may cause malfunction of PCB.
1. Remove the electrical box.		
1 Loosen the screw marked and pull the electrical control box cover out		
2		■ When assembling, insert the left hook of the drip proof plate into the hem plate of the heat exchanger.
		

9.7 Removal of Heat Exchanger

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Loosen the screws fixed to the installation plate.	■ You can detach the indoor unit without removing the assembly of the outlet grille. Caution If gas leaks, repair the spot of leaking, then collect all refrigerant from the unit. After conducting vacuum drying, recharge proper amount of refrigerant.
2	Loosen the marked hooks	Caution Do not contaminate any gas (including air) other than the specified refrigerant (R410A), into refrigerant cycle. (Contaminating of air or other gas causes abnormal high pressure in refrigerating cycle, and this results in pipe breakage or personal injuries.)
3	Loosen the marked screws and remove mounting plate	■ Pay attention so that the residual water in the drain will not make the floor wet. ■ In case that a drain hose is buried inside a wall, remove it after the drain hose in the wall is pulled out. ■ Use two wrenches to disconnect pipes. ■ When disconnecting pipes, cover every nozzle with caps so as not to let dust and moisture in.









Step	Procedure	Points
1	Release the hooks	
2	Release the hook from the back side. Lift up the lower part of the fixture plate and remove it.	 
6	Remove the heat exchanger	 

9.8 Removal of Fan Rotor and Fan Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the right side plate.		
1 Loosen the 2 screws.		
2 Remove the fixing plate.		
		
		

Step	Procedure	Points
3. Remove the fan.		
1	Loosen the marked screw.	
2	Lift up the right part of the fan motor and slide it to the rightward to remove.	
3	Lift up the right part of the fan and remove it	











9.2 For Outdoor unit

9.2.1 Removal of Outdoor Panel

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Features		
1	Loosen the screw of the stop valve cover. Pull down the stop valve cover and remove it.	■ Be careful not to cut your finger by the fins of the heat exchanger. ■ The stop valve cover is united with the shelter. ■ When assembling, make sure to fit the 5 hooks.







Step	Procedure	Points
2. Remove the panels.		
1 Loosen the top panel screws		
2 Lift the top panel		

Step	Procedure	Points
3	Loosen the csrews and pull the panel	





9.2.2 Removal of Electrical Box

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the fixing screws Then lift the electrical box	





9.2.3 Removal of Fan and Fan Motor

Procedure

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure		Points
1	Loosen the fixing screw and remove the fan	 	 ■ Put the lead wire through the back of the motor when assembling. (so as not to be entangled with the propeller fan)

Step	Procedure		Points
2	Loosen the fixing screws and remove the motor	 	

9.2.4 Removal of fan motor Bracket and Partition

Procedure

Warning Be sure to wait 10 minutes or mo
before disassembling work.

Step	Procedure		Points
1	Loosen the fixing screws and lift the fan motor bracket.	 	

Step	Procedure	Points
3	Loosen the screw and remove the reactor	■ When assembling ,fit the lower hook into the bottom frame .
4	The partition plate has a hook on the lower side.Lift and pull the partition plate to remove.	









9.2.5 Removal of Computor and Heat Exchanger

Procedure

Warning Be sure to wait 10 minutes or more after tu before disassembling work.

Step	Procedure		Points
1	Loosen the marked screws and pull out the backgurd	 	

Step	Procedure		Points
4	Remove the compre -ssor and pipe assay		
5	Remove the conden -ser	 	

10.Wiring Diagrams

10.1.INDOORUNIT



10.2.Outdoor unit



WARNING

CAUTION

DON'T TOUCH CAPACITOR, EVEN AFTER PLUG-OFF (DANGER OF ELECTRIC SHOCK)

The capacitor retains high voltage even after the plug-off. For your safety, be sure to wait at least 5 minutes. after plug off and use a tester to confirm the voltage between connector P and N(on module board) is less than DC 10V before start servicing.

Description	LED1 Flash Times
Outdoor EEPROM error	1
The protection of IPM	2
Overcurrent protection of AC electricity	3
Communication fault between the IPM and CBD	4
Over pressure or Overheat protection for the compressor	5
Power voltage is too high or low	6
Overheat protection for exhaust temperature	8
Frost-removing temperature sensor failure	10
Ambient temperature sensor failure	12
Exhaust temperature sensor failure	13
Deviate from the normal for the compressor	18
Loop of the station detect error	19
Overcurrent of the compressor	24
Overcurrent protection for single-phase of the compressor	25

11.Circuit Diagrams

11.1.INDOORUNIT



11.2.OUTDOORUNIT

11.2.1 module board Circuit Diagrams



11.2.2 control board Circuit Diagrams




N
P
R19
47
C3
102/100V
+12V
IC4
L7805CV
Vin
GND
Vout
+5V
E22034
T1
D8
10 MBR3100\ER302
E7
470U/25V
C8
104/50V
R22
1K/0.5W
E8
100U/16V
C9
104/50V
R14
100K/2W
CY8
472/1KV
D10
ER106
CX5
104/275V
ZD1
IN5948B
R24
5.1K/1%
D7
6 MBR1100\SB1100
E5
470U/25V
L3
20UH/1A
R29
47
E6
100U/16V
C7
104/50V
+5VD
R28
5.1K/1%
R20
220
R21
220
CY9
222/250VAC
IC1
ADJ HV
FB NC
CS VCC
GNDDRV
NCP1200P100
R25
10K
R90 0
J114
R18 47
C2
102/100V
+15V
CN22
D9
4 MUR115\MUR130\ER106
E4
470U/25V
C6
104/50V
R17
330/1W
R26
1K
R15
15
R27
10K
M1
IRFUC20
E3
22U/25V
R32
5.1K/1%
IC3
TL431C
C4
103/50V
R16
2/1W
IC2
PC817A
R30
1K
R31
1K
C5
104/50V


1
2
3
4
D
C
B
A
CN26
P
R23
220K/2W
E1
680U/400V/450V
E2
680U/400V/450V
CX6
105/275VAC
LED2
POWER
P
N
CN24
N

12.Description of coding rules of unit model


H S U 0 9 V H J (D B)
DC Inverter
The series number
H-heat pump
Applicable voltage:V(230/208V)
Nominal cooling capacity (9000BTU/h)
The structure code of indoor & outdoor unit: S(wall-mounted)
H-Abbreviation of Haier

Examples:

HSU-07RD03/R1,It represents wall-mounted split type heat pump air conditioner.The cooling capacity is 7000BTU/h,and the power supply is 220-230V/50Hz,”D” means the developing sequence,and"R1" means the refrigerant is R407C.

Sincere Forever

Haier Group

Haier Industrial Park, No.1, Haier Road

266101, Qingdao, China_

E-mail: hractech@haier.com

Tel: +86 532 88936935

Http://www.haier.com

Edited by : Li Jingsheng
Cui Xiaogao

Signed by : Yang Bifei

Approved by: W u Hongjin